

Sewing Pattern — Top 5556

Recommendations on fabric: silk / viscose

You will also need: 8 eyelets; fusing

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams, 3 cm for hem

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Upper front part – 2 pieces
2. Back part – 2 pieces
3. Front facing – 4 pieces
4. Back facing – 4 pieces
5. Front inset – 2 pieces
6. Back inset – 2 pieces
7. Lower back part – 1 piece
8. Lower front part – 1 piece

Fusing: front/back facing

INSTRUCTIONS:

1. Apply the fusing to wrong side of front/back facing.
2. Stitch upper front darts, press them towards front center.
3. Stitch front inset to upper front part. Neaten the seam and press it toward the inset.
4. Stitch back inset to upper back part. Neaten the seam and press it toward back inset.
5. Stitch the facing to upper front part. Press the seam towards the facing.
6. Stitch back facing to upper back part. Press the seam toward back facing.
7. Neaten middle back edge, stitch it and press the seam apart.
8. Neaten front/back armhole edges and topstitch them.
9. Neaten top's shoulder edges. Stitch shoulder edges and press them apart. Topstitch at 1 cm on both sides of shoulder seam.
10. Cut fabric stripes for ties. Fold the tie along the center wrong side out, adjust edges and overstretch at 0.5-0.7 cm from edges. Fold the tie right side out, place the seam on bending, then press the seam.
11. Pull ties into shoulder seams.
12. Stitch middle seam of back neckline inner facing, then press it apart. Neaten facings' outer edge. Fold inner facings on outer ones coinciding shoulder seams, then overstretch. Topstitch overstretching allowances on inner facing at 0.2 cm from seam. Topstitch facing's neaten edge on the seam joining the facing.
13. Make loose-looped stitch at 0.5 cm from back/front parts' upper edge. Pull detail's upper edge correspondingly to front/back inset lower edge.
14. Stitch back part's lower edge to back inset. Neaten the seam and press it toward the inset.
15. Stitch lower front part to front inset to that front parts meet. Neaten the seam and press it toward the inset.
16. Stitch top's side seams and neaten them. Press side seams backwards.
17. Neaten top's hem, fold it under and topstitch.
18. Set eyelets into front edgings. Pull the cord into eyelets.

TECHNICAL DRAWING:

