

# Sewing Pattern — Jacket 5552

Recommendations on fabric: natural/mixed fabric

You will also need: fusing; 4 buttons; lining; shoulder pads

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowances: 1 cm for all seams, 3 cm for garment/sleeve hems

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



## **CUTTING**:

## Main fabric:

- 1. Back part 2 pieces
- 2. Front part 2 pieces
- 3. Front band 2 pieces
- 4. Back neckline facing 1 piece
- 5. Flap 4 pieces
- 6. Inner collar 1 piece
- 7. Outer collar 1 piece
- 8. Sleeve 2 pieces
- 9. Cuff 2 pieces

#### Lining:

1. Front part – 2 pieces

<u>Fusing:</u> front band, back neckline facing, front part, flap, outer collar, cuff.

# **INSTRUCTIONS**:

- 1. Apply the fusing to wrong side of front band, back neckline facing, front part, flap, outer collar, cuff.
- 2. Stitch front/back darts, slash depths. Press front darts apart. Neaten back darts and pres them towards back center.
- 3. Lay flaps right sides together, then overstitch. Cut allowances of flap's corners, then turn them



right side out. Lay outer collar on inner one, then overstitch. Cut seams in corners, turn right side out and press the collar.

- 4. Stitch the flap's place on front part, fold it under and topstitch.
- 5. Pin front band on front part right sides together and overstitch along edging. (Topstitch front part upwards.) Cut edgings' upper corners. Remove pins. Tack overstitching allowance on front band at closure segment, and on edging at lapels.
- 6. Stitch middle back seam, neaten it and press it apart.
- 7. Stitch darts into lining front part. Neaten shoulder edge of lining font part. Press darts. Neaten back hem. Press the hem into wrong side of front/back parts. Stitch the lining to front band's outer edge and overstitch the hem with lining.
- 8. Stitch side edges folding back hem allowance into back part's right side as following: front part inserts into back hem lining. Neaten side edges and press fold back hem allowance into wrong side.
- 9. Neaten shoulder seams, stitch them and press them apart. Stitch shoulder edges of front band/facing. Press seams apart. Stitch outer collar into facing neckline, stitch inner collar into front/back necklines. Press joining seams apart and fix allowance close to seams. Fix lining shoulder edges' allowance to jacket's shoulder edge.
- 10. Make pleats into sleeve caps and sleeve hems. Press cuffs along the center right side out. Stitch side edge, press side seam apart. Press cuffs along the center. Neaten sleeve seams, then stitch them and press them apart. Stitch cuffs to sleeve hems. Neaten joining seams.
- 11. Stitch sleeves into armholes according to notches. Neaten joining seams. Make decorative stitch at 0.5 cm from edging, along collar contour and jacket hem. Remove tacking.
- 12. Make buttonholes into right front part, sew buttons on lift one.

## **TECHNICAL DRAWING:**

