

## Sewing Pattern — Jacket 5551

Recommendations on fabric: natural/mixing fabric

You will also need: fusing, separating zipper, lining; shoulder pads

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams, 3 cm for garment/sleeve hems

<u>Attention</u>! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING**:

### Fabric:

- 1. Back part 2 pieces
- 2. Front part 2 pieces
- 3. Yoke 2 pieces
- 4. Back neckline facing 1 piece
- 5. Front band 2 pieces
- 6. Upper sleeve 2 pieces
- 7. Lower sleeve 2 pieces
- 8. Half-belt 2 pieces
- 9. Pocket 2 pieces
- 10. Flap 4 pieces
- 11. Belt 2 pieces

Lining:

- 1. Back part 2 pieces
- 2. Front part 2 pieces
- 3. Yoke 2 pieces
- 4. Upper sleeve 2 pieces
- 5. Lower sleeve -2 pieces
- 6. Pocket 2 pieces



Fusing: front band, back neckline facing, front part, flap, outer collar, yoke

#### **INSTRUCTIONS:**

1. Apply the fusing to wrong side of front band, back neckline facing, front part, flap, outer collar, yoke.

2. Stitch front/back darts, slash darts' depths. Press front/back darts apart.

3. Lay flaps right sides together, then overstitch. Cut allowances of flap's corners, then turn them right side out. Lay outer collar on inner one, then overstitch. Cut seams in corners, turn right side out and press the collar.

4. Mark pocket's place. Lay pocket details right sides together and stitch upper edges together. Stitch pockets' edges along the contour leaving a 5-cm hole into side seam. Cut allowances of rounded corners and turn the pocket right side out. Press the pocket. Topstitch the pocket in accordance with marking. Mark flap place. Stitch the flap on marking. Fold the flap downwards and topstitch at 0.5 cm from joining seam.

5. Lay front parts right sides together measuring edgings' lengths. Stitch the zipper to edging. Press edgings into wrong side at closure segment.

6. Stitch side/shoulder seams and press them apart.

7. Stitch shoulder edges of back neckline facing/front band, then press seams apart. Overstitch front/back necklines. Turn facing into wrong side, press seams.

8. Pin front band on front part right sides together and overstitch along edging and front/back necklines. (Topstitch front part upwards.) Stitch lower edges of front bands to front part along marked hem line. Cut edgings' lower corners. Turn edgings right side out. Topstitch edgings at 0.5 cm distance.

9. Fold half-belt along the center wrong side out, overstitch along three edges leaving belt's side edge free. Turn half-belt right side out and press it. Stitch half-belt to elbow edge.

10. Stitch elbow seams and press it apart. Press sleeve hems into wrong side. Stitch sleeve front seams and press them apart. Fix half-bent on sleeve front seam with a stitch equal to half-bend's width.

11. Stitch sleeve into armholes according to notches. Sew shoulder pads.

12. Stitch lining details together and stitch sleeve in, leaving a hole into right front seam of a sleeve and waistband hole into left side seam.

13. Stitch the lining to inner edges of front bands/back neckline facing.

14. Stitch the lining to jacket/sleeve hems. Turn the jacket right side out trough sleeve hole. Stitch hole's edges together.

15. Fold the belt along the center wrong side out, then overstitch along three edges leaving a hole of 5-7 cm (in belt's longer edge.) Turn the belt right side out and press it. Topstitch belt's contour at 0.5 cm from edge.



# TECHNICAL DRAWING:

