

Sewing Pattern — Dress 4227

Recommendations on fabric: natural or mixed thin fabrics suitable for dresses

You will also need: fusing, 12 buttons

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: all seams - 1 cm, hem of the garment - 2 cm

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Main fabric:

1. Central back part – 2 details
2. Side back part – 2 details
3. Back yoke – 2 details
4. Side front part – 2 details
5. Central front part – 1 detail
6. Front part yoke – 4 details
7. Placket – 2 details
8. Flap – 4 details
9. Stand-up part of collar – 2 details
10. Collar – 2 details
11. Sleeve – 2 details
12. Cuff – 4 details

Fusing:

1. Placket – 2 details
2. Flap – 2 details
3. Stand-up part of collar – 1 detail
4. Collar – 1 detail
5. Cuff – 2 details

INSTRUCTIONS:

1. Apply fusing to details.
 2. Sew princess seams on back part, press seam allowances towards center and serge. Sew center edge of back part, press seam onto left side and serge.
 3. Fold yokes of back part right sides together and overstitch lower edge. Slash seam allowances, turn yoke onto right side, press. Make buttonhole. Put yoke onto back part and fix along neckline edge, armholes, shoulder edges.
 4. Press plackets in half lengthwise wrong sides together. Serge buttonholes on right placket. Make cross slashes in corners on front part, leaving 1 mm to seam line. Stitch outer parts of plackets to front part, press seam onto the placket. Turn open edges of inner and topstitch into connecting seam. Put right placket onto left one and sew from the wrong side to lower neckline edge. Serge seam allowances.
 5. Fold flaps details right sides together and overstitch. Slash seam allowances in corners of flaps and turn onto right side. Straighten and press seams. Make buttonholes.
 6. Sew princess edges of front part, inserting flaps, press seam allowances towards center and serge.
 7. Fold yokes of front part right sides together and overstitch lower and front edge. Slash seam allowances away in corner, turn yokes onto right side, press. Put yokes onto front part and fix along neckline edge, armholes and shoulder edges.
 8. Sew side and shoulder edges. Press allowances of side seams towards back part and serge. Press apart and serge allowances of shoulder seams.
 9. Fold top collar with lower right sides together. Overstitch ends and outer edge of collar. Cut the seams off. Turn collar out, straighten and press. Fold stand-up collar details right sides together, insert ready collar between them, level notches and sew, overstitching ends of stand-up collar at the same time. Start and finish the stitch exactly near marked line of stand-up collar connecting seam. Turn ready collar out and press.
 10. Sew outer stand-up part of collar and the collar into the neckline, turn open edge of inner stand-up part of collar and topstitch into connecting seam.
 11. Sew edge of sleeve. Press and serge seam allowances. Sew sleeve into armhole, leveling notches and easing in on rounded part. Press and serge seam allowances.
 12. Sew cuffs into ring, press seam allowances apart. Fold cuffs pairwise right sides together and overstitch upper edge. Turn onto right side, straighten, press. Make buttonhole. Insert cuff into the sleeve and stitch to lower edge. Serge. Turn cuff onto right side.
 13. Serge hem of garment. Press hem onto wrong side and topstitch.
 14. Make buttonhole on right side of the stand-up collar. Sew buttons according to all buttonholes.
- ADVICE: Wear the dress with the belt.

TECHNICAL DRAWING:

