

Sewing Pattern — Jacket 5512

Recommendations on fabric: natural/mixed fabric

You will also need: fusible interfacing, lining, 3 buttons, shoulder pads

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: 1 cm for all seams, 3 cm for hem

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.



CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Fabric:

1. Upper front – cut 2
2. Inner collar – cut 1
3. Outer collar – cut 1
4. Center front – cut 2
5. Side front – cut 2
6. Back neck facing – cut 1
7. Side back – cut 2
8. Center back – cut 2
9. Front facing – cut 2
10. Upper sleeve_1 – cut 2
11. Upper sleeve_2 – cut 2
12. Lower sleeve – cut 2

Lining:

1. Upper front – cut 2
2. Center front – cut 2
3. Side front – cut 2
4. Center back– cut 2
5. Side back - cut 2
6. Upper sleeve – cut 2
7. Lower sleeve – cut 2

Fusible interfacing: front facing, inner collar, back neck facing

INSTRUCTIONS:

1. Apply the fusible interfacing to wrong side of front facings,, inner collar, back neck facing.
2. Pin collar right sides together, and sew outer edges. Trim corners, and turn right side out. Press the collar.
3. Sew dart on upper front or gather between legs of dart.
4. Sew side front to center front. Press seam apart. Sew lower front to upper front. Press seam apart.
5. Sew back shoulder dart, press toward center. Sew center back seam and press apart. Sew side back to center back. Press seam apart.
6. Sew shoulder/side seams of the garment and press seams apart.
7. Gather upper sleeve_1's lower edge; the gather must be equal to length of upper sleeve_2's upper edge. Sew upper sleeve - 1 to upper sleeve - 2. Sew sleeve front seam and press it apart. Press sleeve hems under.
8. Pin front facing to front, right sides together, and sew along center front to the notch for collar. Sew front facing lower edge to center front along marked hemline. trim corners, and understitch. Turn right side out and press. Sew back neck facing to front facing, press seams apart.
9. Sew inner collar to garment neckline. Sew outer collar to facing.
10. Make a gathering stitch along sleeve cap for ease. Sew sleeves into armholes matching notches and adjusting ease.
11. Sew lining same as main fabric, leaving an opening in sleeve right front seam for turning. Press lining seams. Sew lining to facing inner edges and press collar seams apart and fix close to seams.
12. Sew sleeve lining to fabric sleeve hems and garment hem. Turn the jacket right side out through the opening in the sleeve. Sew up sleeve opening. Tack the lining to jacket at waist level at relieve seam s with 1 cm stitch.
13. Make buttonholes, sew buttons.

TECHNICAL DRAWING:

