

# Sewing Pattern — Blouse 5509

Recommendations on fabric: fabric suitable for suit.

You will also need: fusing, 6 buttons

If the pattern has double contour the seam allowances are included. Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: all seams – 1 cm, 3 cm for all hems

<u>Attention</u>! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



## CUTTING:

## Fabric:

- 1. Back center part 2 pieces
- 2. Side back part 2 pieces
- 3. Inner collar 1 piece
- 4. Outer collar 1 piece
- 5. Side front part 2 pieces
- 6. Center front part 2 pieces
- 7. Front band 2 pieces
- 8. Back neckline facing 1 piece
- 9. Sleeve 2 pieces
- 10. Half-belt 4 pieces

Fusing: front band, back neckline facing, outer collar .

### **INSTRUCTIONS**:

1. Apply the fusing to wrong side of front band, back neckline facing, outer collar.

2. Stitch back darts. Press darts towards back center. Stitch front dart and neaten it. Press front dart towards front center. Stitch front relieve seams and neaten them. Stitch back relieve seams and neaten them. Press front relieve seams towards front center, press back relieve seams towards back center.



3. Stitch back middle seam and neaten it. Press middle seam towards right back part.

4. Lay collar details together and overstitch them along the contour. Slash collar corners and turn them right side out. Press the collar.

5. Pin front band on front part right sides together and overstitch them along edging (at front part side up to the notch determining edge of collar stitching in). Stitch front bands' lower edges to center front part along marked hem line. Cut edging upper/lower corners. Turn edgings right side our and press it.

6. Neaten garment side edges and stitch them to slit notch. Press side seams apart, press slits. Make decorative stitch at 0.5 cm from slit edge. Stitch garment shoulder and neaten them. Press shoulder seams backwards.

7. Stitch shoulder edges of facing and front band and press them apart. Neaten outer edge of facing and front band.

8. Press joining collar seams' allowance apart and fix them close to seams. Stitch inner collar into garment neckline.

9. Lay half-belt details right sides together and overstitch them along the contour leaving halfbelt lower edge to turn it right side out. Turn half-belt right side out and press it. Make a buttonhole into half-belt. Stitch the half-belt on the sleeve.

10. Stitch sleeve seam and neaten it. Press sleeve seam. Stitch sleeves into armholes according to notches. Neaten sleeve hem, fold it under and topstitch.

11. Make buttonholes into right edging, sew buttons on left one. Sew buttons on sleeves.

## TECHNICAL DRAWING:

