

Sewing Pattern — Coat 4298

Recommendations on fabric: natural or mixed fabric suitable for coats

You will also need: fusible interfacing; lining; shoulder pads; sleeve heads; 23 buttons of 2 – 2.5 cm in diameter

If the pattern has a double line around it, the seam allowances are included.

Note: By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: hem of the garment and hem of sleeve - 4 cm; side edges of pocket frame and of pocket bags – 2 cm; along the edge of lining - 2 cm; other seams - 1 cm

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.

CUTTING:

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

Fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Center left front– cut 1
4. Center right front – cut 1
5. Side front – cut 2
6. Middle upper front — cut 2
7. Middle lower front — cut 2
8. Placket of right front – cut 1
9. Back neck facing – cut 1
10. Front band facing – cut 2
11. Upper sleeve – cut 2
12. Lower sleeve – cut 2
13. Belt – cut 1
14. Upper collar – cut 1
15. Lower collar – cut 1



16. Collar stand – cut 2
17. Flap – cut 2
18. Pocket frame – cut 4

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Front – cut 2
4. Large pocket bag – cut 2
5. Small pocket bag – cut 2
6. Upper sleeve – cut 2
7. Lower sleeve – cut 2

*Attention: cut lining for back using main fabric pattern pieces excluding width of back neck facing.

Fusible interfacing:

1. Center left front – cut 1
2. Center right front – cut 1
3. Side front – cut 2
4. Middle upper front — cut 2
5. Middle lower front — cut 2
6. Placket of right front – cut 1
7. Back neck facing – cut 1
8. Front band facing – cut 2
9. Upper collar – cut 1
10. Inner collar stand – cut 1
11. Flap – cut 2
12. Pocket frame – cut 4
13. Belt – cut 1

Back armhole sections, hem of the garment, vent and hem of sleeve are also interfaced.

INSTRUCTIONS:

1. Apply fusible interfacing to listed pieces.
2. Sew middle upper front to side front. Press seam allowance toward middle upper front, and topstitch at 0.8 cm from the edge. Sew middle lower front to that section. Press seam allowance to middle lower front, and topstitch at 0.8 cm from the edge.
3. Sew that section to center front. Trim corner, press toward center front and topstitch at 0.8 cm from the edge. Sew placket to right front. Press seam allowance onto the placket and topstitch at 0.8 cm from the edge.
4. Pin flap, right sides together, and sew outer edge. Clip into curves and turn right side out and press. Sew the flap along three sides at 0.8 cm from the edge.
5. Mark pocket location and lines for connecting pocket frames on right side of front, continuing the marking line up to given flap length. Fold frames in half wrong sides together and press. Mark additional line on pocket frame (connection line) parallel to the fold. Mark additional line on the flap (connection line) parallel to top edge of the flap. Stitch top pocket bag to the flap. Sew frames to front. Finish the stitches near parallel lines of pockets' marking. Cut the pocket opening. Make slanting cuts at 1-1.5 cm from the end of pocket. Turn frames onto wrong side through the pocket opening, straighten edges, align ends of frames so that pressed folds of the frames come together edge to edge. Fix corners of the pocket from the wrong side with double back stitch. Insert the flap into the pocket and stitch to top frame of pocket. Stitch lower pocket bag into lower frame connecting seam. Sew edges of pocket bags.

6. Sew princess seams of back and of front, press seam allowances apart.
7. Apply interfacing to details of back (from the wrong side). Mark center seam line (vent fold line) from the right side. Press left part of the back along vent fold line. Align details along center seam. Sew center seam of back and vent's corner, leaving 1 cm to vertical edge of the vent. Snip the corner of vent's seam allowance on right part. Press center seam allowances apart, press seam allowances of the vent and fix them on right side with machine stitch.
8. Sew side and shoulder seams. Press seam apart. Serge side seams.
9. Sew upper collar to collar stand, sew lower collar to collar stand. Press seam apart.
10. Pin collar right sides together and sew along outer edge and side edges. Start and finish the seam exactly near marked line of stand-up collar connecting seam. Turn collar/collar stand right side out and press.
11. Sew and press apart shoulder seams of back neck facing and front band facing.
12. Serge and press hem. Pin front band facing to front, right sides together, and sew along center front, up to the notch that determines the end of collar connection. Snip seam allowance near the notch. Stitch lower edge of facing to front exactly on marked hem turnup line, leaving 1.5 cm to inner edge of facing. Trim corners and turn facing right side out, straighten seams.
13. Sew upper collar into the neckline, and lower collar into the neckline of the facing. Press seams apart. Fix seam allowances of collar connecting seam close to seams.
14. Sew elbow sleeve seam and press it upwards. Sew the vent in sleeve. Sew and press apart front sleeve seam. Put short tack stitch along top edge of the rounded part. Make a gathering stitch along sleeve cap for ease and press. *Please note that ease of sleeve is approximately 5 cm. Sew sleeve into the armhole, matching notches and adjusting ease. Sew in shoulder pads and sleeve heads.
15. Sew lining the same way as main fabric pieces. Turn seam allowance of lower edge of lining twice at 1 cm and topstitch. Sew lining to inner edges of facing. Start and finish the stitch in the center of the hem turnup width of the main garment. Snip seam allowance on inner edge of front band facing where you start to connect the lining. Turn inside seam allowance of front band facing from the hem line up to the slash and sew with invisible stitches. Serge the seam of lining and press it towards lining. Sew hem of the garment with invisible stitches. Stitch lining to the vent.
16. Make a decorative stitch at 0.8 cm from the edge of center front and collar. Put fixing stitch along collar and collar stand connecting seam.
17. Sew lining to lower edge of sleeves. Turn the coat right side out.
18. Make buttonholes on right front, sew buttons on left front. Sew buttons on the sleeve.
19. Fold belt in half lengthwise, right sides together, and sew along the contour, leaving an opening in on the long side for turning. Turn the belt right side out, turn inside seam allowances of unsewn section and sew with invisible stitches. Make a decorative stitch at 0.8 cm from the edge along the perimeter of the belt. Pin the belt onto back and attach with buttons.

TECHNICAL DRAWING:

