

## Sewing Pattern — Two-Layer Dress 5498

Recommendations on fabric: fabric suitable for dress (natural or mixed).

You will also need: a zipper.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams, 3 cm for hems.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Fabric:

1. Outer front part – 1 piece
2. Inner front part – 1 piece
3. Inner back part – 2 pieces
4. Left outer back part – 1 piece
5. Right outer back part – 1 piece
6. Sleeve – 2 pieces

### **INSTRUCTIONS:**

1. Stitch bust darts into outer/inner layers of front part. Press bust darts downwards. Stitch waist darts into outer/inner back part. Press shoulder darts towards back center. Stitch darts into outer back part. Press darts towards back center.
2. Neaten side/shoulder edges of outer/inner layers. Stitch shoulder seams of outer/inner layers. Stitch side seams of outer/inner, leaving a slit into left lower seam of inner layer. Press side/shoulder seams apart, pressing side slit. Make decorative stitch along the slit.
3. Neaten outer front/back parts' hem. Press it under and topstitch.
4. Lay outer layer right side on inner layer wrong side. Overstitch front/back neckline edge. Topstitch neckline overstitch allowance on inner layer at 0.2 cm from joining seam.

5. Neaten outer/inner layers middle edge (as a single detail). Stitch middle seam up to closure notch. Press back middle seam apart, press closure slit. Sew the zipper into middle seam.
6. Neaten sleeves hem and press them under. Stitch sleeve edge and neaten it folding out sleeve hem. Topstitch sleeve hems.
7. Stitch sleeves into armholes (two layers as a single detail). Neaten the joining seams and press it towards armholes.
8. Neaten inner hem, press it under and topstitch.

**TECHNICAL DRAWING:**

