

Sewing Pattern —Blouse with Decorative Sleeves 5473

Recommendations on fabric: silk.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams, 2 cm for sleeve upper edge and edges of front/back neckline.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Sleeve – 2 pieces
2. Front part - 1 piece
3. Back part – 1 piece
4. Cord – 1 piece
5. Slit facing – 1 piece

INSTRUCTIONS:

1. Sew sleeve edges. Neaten joining seam and press it apart.
2. Mark slit into front part and cut it. Press slit facing along the center. Sew folded facing to slit, with facing fold is on the garment at 0.75 cm width. Cut seam allowance to 0.5 cm width. Turn facing to wrong side and topstitch garment along slit.
3. Neaten garment side edges. Sew side edges to slit notch and press it apart. Make decorative stitch along slit.
4. Sew sleeves in armholes and neaten joining seam.
5. Neaten sleeve upper edge, front/back neckline edge. Press ready edges to wrong side and topstitch.
6. Fold cord along the center and make a stitch at 0/5-0/7 cm from cord edge. Turn cord right side out and press it. Trim ties short ends in and sew by hand. Pull the cord in and tie it (cord patterns given with allowance).
7. Neaten garment hem and sleeve hem, press to wrong side and topstitch at 0.5 cm from edge.

TECHNICAL DRAWING:

