

Sewing Pattern — Waistcoat 5454

Recommendations on fabric: wool or semi-wool.

You will also need: fusing, 1 button, zipper, decorative braid, lining.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams, 3 cm for hem.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Back part – 2 pieces
2. Front part – 2 pieces
3. Stand-up collar – 2 pieces
4. Flap – 4 pieces
5. Pocket – 2 pieces
6. Front band – 2 pieces
7. Upper pocket facing – 2 pieces
8. Side pocket facing – 2 pieces

Lining:

1. Back part – 2 pieces
2. Front part – 2 pieces
3. Upper pocket lining – 4 pieces
4. Side pocket sacking – 4 pieces

Fusing: outer stand-up, front band.

INSTRUCTIONS:

1. Apply the fusing to wrong side of upper stand-up collar and front band.
2. Sew back dart, press back darts towards back center. Sew front dart. Press front dart downwards.
3. Fold facings of upper pocket and side pocket along the center, wrong side inside, and press them.
4. Apply stripe of fabric to pocket enter. Mark an auxiliary line at pocket facing which is parallel to facing bending (stitching line). Mark auxiliary lines going parallel to pocket entrance (to sew facing and pocket lining). Sew facing and pocket lining to marked line. Sew pocket lining at distance equal to ready facing width. Cut pocket entrance stopping 1.5 cm before ends. Make diagonal notches at 1.5 cm from pocket end. Pull the lining and facing right side out through this slit. Fix pocket ends with double stitch at corners basing (on wrong side). Sew the zipper in and sew lining second part to facing allowance. Slash pocket sacking and stitch it. Do the same for upper and side pockets. Press ready pocket.
5. Fold flap details right side inside, then overstretch. Slash allowances of flap corners, then turn right side out. Press ready flap.
6. Neaten upper edge of patch pocket. Press upper allowance of patch pocket, then topstitch it. Overstretch patch pocket outer contour and press allowances in accordance with patterns, leaving pocket side slit free.
7. Mark place of pocket and topstitch it on front part at 0.5 cm from pocket edge.
8. Sew the zipper to front edges.
9. Lay front band on front part's right side. Right sides together, pin, and overstretch along edging. Overstretch edging along front part up to the notch pointing end of sewing stand-up collar in. Sew lower edges of front bands to front part strictly along marked hemline. Cut seams of upper/lower corners of edging. Turn edgings right side out. Measure lengths of edgings and make decorative stitch along edging at 0.7 cm from edge.
10. Overstretch lower stand-up collar with lower one; turn stand-up right side out, slash corners and press the collar.
11. Sew back middle seam and press it apart. Sew shoulder/side seams and press them apart.
12. Sew the flap. Turn the flap into right side and topstitch 0.5 cm from joining seam.
13. Sew seams into lining, leaving a slit into right side seam. Press the seam towards front center, press back seams towards back center.
14. Sew lower stand-up collar into garment neckline, sew upper stand-up collar into lining waistcoat. Press allowances of seams joining stand-ups, close to seams.
15. Overstretch front/back necklines with lining. Topstitch overstretch allowances at 0.2 cm from the seam. Sew the garment to front band outer edges and garment hem. Turn the waistband right side out through side seam. Sew the slit into side seam.

TECHNICAL DRAWING:

