

Sewing Pattern — Corset 5440

Recommendations on fabric: denim.

You will also need: fusing, a cord.

Seam allowances are provided if the pattern has double contour.

Seam allowances are NOT included if the pattern has single contour and need to be added when laying out and cutting details.

Seam allowance 1 cm on all edges.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count double and symmetrical details.

When sewing the garment, pay attention to notches, they must coincide.

CUTTING:

Fabric:

1. center front part – 2 pieces
2. placket – 2 pieces
3. side front part – 2 pieces
4. center back part – 2 pieces
5. side back part – 2 pieces

Fusing: placket.

INSTRUCTIONS:

1. apply the fusing to wrong side of placket.
2. sew front/back relieve seams. neaten front/back relieve seams. press relieve seams toward the center. make decorative seam at 0.5 cm from relieve seams.
3. sew back middle seam, and neaten it. press back middle seam towards right back part. make decorative seam at 0.5 cm from joining seams.
4. sew shoulder and side seams, then neaten them. press side/shoulder seams backwards. make decorative seam at 0.5 cm from joining seams.
5. neaten front/back neckline edge, front part edge and garment hem edge. topstitch ready edges on the garment at 0.5 cm from edge.
6. press placket outer edge at 1 cm. fold the placket along the center, right side together, and press. overstretch upper/lower corners of placket. cut extra fabric at corners, and turn the placket right side out. press the placket. sew placket raw edge to middle edge of center front part.
7. cut a stripe of fabric for button loops of 3 cm width. fold the stripe along the center and make a stitch at 0.5 cm from bending, overstretching one end. turn the stripe right side out and press. cut loops of 6 cm length.
8. tack loops to placket pressed edge. topstitch the placket on center front part. remove tacking. turn loops towards center front part and topstitch them on the placket.



TECHNICAL DRAWING:

