

## Sewing Pattern — Denim Coat 5439

Recommendations on fabric: denim.

You will also need: fusing, 3 buttons.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams, 3 cm for hem.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Fabric:

1. Belt loop – 1 piece
2. Center back part – 2 pieces
3. Side back part – 2 pieces
4. Inner collar – 1 piece
5. Outer collar – 1 piece
6. Side front part – 2 pieces
7. Center front part – 1 piece
8. Front band – 2 pieces
9. Pocket detail – 2 pieces
10. Sacking – 4 pieces
11. Upper sleeve – 2 pieces
12. Lower sleeve – 2 pieces

Fusing: front band, pocket detail, pocket detail, front part, garment hem, sleeve hems.

## **INSTRUCTIONS:**

1. Apply the fusing to wrong side of front band, pocket detail, pocket strengthener, front part, garment hem, sleeve hems.
2. Neaten back middle seam, side edges of side front part and side back part, relieve edges of center front/center back parts, front/back shoulder edges.
3. Sew front/back relieve seams, then press them apart.
4. Fold pocket detail along the center, right side inside, and press. Neaten corners, cut extra fabric in corners, and turn pocket detail right side out. Press the detail.
5. Fold outer collar and inner collar together, then overstretch. Turn the collar right side out, and press it.
6. Mark pocket detail with line of joining to front part, measuring the width. Mark pocket place on front part. Lay pocket detail its wrong side (and ready edge down) on right side of pocket lining's one part, coinciding edges, with lining edges beyond pocket detail at same width. Lay pocket detail on front part and coincide marking of front part and pocket detail. Sew pocket detail to front part (pocket detail of between front part and pocket lining). Turn the seam joining pocket detail and lining towards pocket detail. Lay the rest of lining on front part, right sides together, to seam joining pocket detail. Tack and stitch it at 0.8-1 cm from seam joining pocket detail. Stitches must be parallel to each other. Remove tacking. Cut pocket entrance. Make diagonal notches at 1-1.5 cm from pocket end. Turn pocket detail and sacking into wrong side through this slit. Fix pocket ends on wrong side with reverse double stitch along basing of corners. Sew sacking and neaten it. Tack pocket detail to front part and press it. Topstitch pocket detail's ends. Remove tacking.
7. Press edge of lower vent at 1 cm and topstitch on back central part. Sew back middle edge. Press back middle seam apart stopping 5 cm before the vent. Press the vent towards back center. Topstitch back middle seam diagonally close to vent top, along marking, catching vent allowance.
8. Sew shoulder/side seams, and press them apart.
9. Neaten inner edge of front band. Pin front band and front part right sides together, and overstretch along edging (on front part side, sewing the collar in). Topstitch edging facing allowance as following: at closure – on front band, at lapels – on front part edging (topstitch it at 0.2 cm from seams). Turn lapels right side out. Neaten seam joining the collar and topstitch.
10. Sew sleeve elbow seam and vent corners at sleeve upper/lower parts. Press elbow seam apart, make a notch and press the vent.
11. Sew sleeve front seam and press it apart.
12. Sew sleeves into armholes coinciding notches, neaten joining seam.
13. Neaten garment hem and sleeve hems, then press hems over along hemline and sew.
14. Make a buttonhole into front right edge, sew the button on left one. Sew the button on sleeve vent.
15. Fold belt loop along the center, right side inside, coincide edges and overstretch at 0.5-0.7 cm from edges. Turn right side out, place the seam at bending or make edging of 0.1-0.2 cm to wrong side, then press. Cut belt loops and topstitch on side seams.

**TECHNICAL DRAWING:**

