

## Sewing Pattern — Top 5420

Recommendations on fabric: jersey

You will also need: zip, 1 button, bias binding and fusing

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Fabric:

1. Collar - 2 pieces
2. Back – 2 pieces
3. Upper front - 2 pieces
4. Lower front - 1 piece

Fusing: top collar .

ADVICE: to prevent seam from stiffing, sew stitch pieces with special (zigzag) stitch. To prevent hem from stiffing neaten it with an overlocker and then stitch using double needle for jersey. Do the same for all edges must stay elastic.

The above is not for industrial manufacturing.

### **INSTRUCTIONS:**

1. Apply the fusing to the wrong side of the top collar.
2. Stitch the back darts; press them towards the back centre.
3. Stitch the back centre edges; neaten the seam; press the seam allowances to the right piece.

4. Finish the front decorative opening by applying a bias binding. Neaten the front centre edges; stitch them; press the seam open.
5. Make narrow pleats at the upper front lower edge; stitch the upper front piece to the lower front. Neaten the seam; press the seam allowances upwards.
6. Stitch the shoulder seams; neaten and press them backwards.
7. Neaten the garment side edges; stitch the side seams leaving a zipper opening in the left side seam. Press the seams open. Insert the zip.
8. Make up and shape the collar. Press the top collar lower edge under.
9. Stitch the under collar to the neck edge; topstitch the top collar to the neckline seam.
10. Neaten the armhole edges; press the seam allowances under and topstitch 0,5 cm in. You can also finish the armholes by applying bias binding.
11. Make a loop; attach the loop to the right front piece; sew a button on the left piece.
12. Neaten the garment hem; press the hem under and topstitch.

**TECHNICAL DRAWING:**

