

Sewing Pattern — Skirt 5356

Recommendations on fabric: denim

You will also need: fusing, zipper

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowances: 1 cm for all seams

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Upper gusset – 2 pieces
2. Upper inset – 2 pieces
3. Upper inset-2 – 2 pieces
4. Centre inset – 2 pieces
5. Diagonal inset – 2 pieces
6. Facing – 2 pieces
7. Front right flounce – 1 piece
8. Front left flounce – 1 piece
9. Side left panel – 1 piece
10. Back gusset – 1 piece
11. Back flounce – 1 piece
- 12.

Fusing: facings.

INSTRUCTIONS:

1. Apply the fusing to the wrong side of the facings.
2. Stitch the front curved edges: upper gusset, upper insert-1, upper insert-2, centre inset and diagonal inset. Neaten the seams and press them. Stitch the back pieces using the same method.
3. Stitch the front right flounce to the diagonal inset, neaten and press the joining seam.

4. Stitch the front left flounce to the side left panel, neaten and press the joining seam.
5. Stitch the back gusset to the back diagonal inset, neaten and press the joining seam.
6. Stitch the back flounce to the back gusset, neaten and press the joining seam
7. Stitch the front/back side edges leaving a zipper slit.
8. Sew the zipper in. Stitch the front/back facing side right edges. Neaten the facing lower/side left edges.
9. Neaten and press: front right flounce/lower flounce/front left flounce lower edges. Press the edges under; topstitch them to the garment. Neaten and press the front left flounce/ side left piece centre edges under; topstitch them.
10. Stitch the facing side edges. With right sides together, overstretch the front/back panel upper edges with the facing. Topstitch the seam allowance to the facing 0.2 cm away from the seam.
11. Slipstitch the ends of the facing to the zip tape.

TECHNICAL DRAWING:

