

Sewing Pattern — Coat 5343

Recommendations on fabric: denim

You will also need: fusing; 9 poppers, and sateen for underlining

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Seam allowance : 1 cm for all seams, 3 cm for hem and sleeve lower edges

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Back neck facing – 1 piece
2. Stand collar – 2 pieces
3. Lower pocket facing – 2 pieces
4. Lower patch pocket – 2 pieces
5. Lower flap – 4 pieces
6. Upper pocket facing – 1 piece
7. Upper patch pocket – 1 piece
8. Upper flap – 2 pieces
9. Back trimming – 2 pieces
10. Front trimming – 4 pieces
11. Upper back – 2 pieces
12. Centre back – 2 pieces
13. Side back - 2 pieces
14. Side front - 2 pieces
15. Upper front - 2 pieces
16. Centre front – 2 pieces
17. Front facing – 2 pieces
18. Epaulet – 4 pieces
19. Upper sleeve – 2 pieces
20. Lower sleeve – 2 pieces

Lining:

1. Centre back – 2 pieces
2. Upper back – 2 pieces
3. Upper front – 2 pieces
4. Side back – 2 pieces
5. Side front – 2 pieces
6. Centre front – 2 pieces
7. Upper sleeve – 2 pieces
8. Lower sleeve – 2 pieces

Fusing: front facings; one stand collar piece; back vent; under flaps; back/front trimmings

INSTRUCTIONS:

1. Apply fusing to the wrong side of the facings; under stand collar piece; side back vent; under flaps; front/back trimmings.
2. Make up and shape the collar.
3. Stitch the side edges of the front/back trimmings and press the seams open. Pin the trimmings together with right sides inside and stitch them. Trim the extra fabric on the curved edges of the front trimmings. Turn it right side out and press.
4. Stitch the darts at the front/back upper pieces. Press them open. Stitch the curved edges of the side/centre front pieces. Press them open. Stitch the curved edges at the front/centre back pieces. Press them open.
5. Stitch the pieces of the epaulet together inside out leaving a slit in one edge. Turn them right side out and press flat.
6. Stitch the side edges of the upper front/back pieces. Press the seams open. Stitch the shoulder seams and press them open. Tack the trimming to the upper front/back pieces.
7. Stitch the back centre edges up to the slit. Fold the edge of the under vent to the wrong side and press it. Press the centre seam open and topstitch it diagonally above the upper vent end according to the mark through the vent seam allowances.
8. Stitch the side seams. Press them open. Stitch the upper front/back pieces to the lower pieces. Remove the temporary stitches from the trimming.
9. Stitch the elbow seams and press them open.
10. Stitch the top flap and edgestitch it with double decorative stitch 0.2 cm in from the edge. Stitch the lower flaps the same way. Mark the pocket position on the sleeve. Neaten the side edges of the upper pocket facing. Stitch it to the side/lower edges of the pocket and neaten the edges. Fold the top pocket edge inside and topstitch it to the pocket. Make a split on the pocket facing and fix it with diagonal stitch for 1 – 1,5cm. Place the pocket according to the marks and topstitch to the sleeve. Topstitch the flap and turn it downwards. Topstitch the flap on the right side 0,2 cm below the seamline. Make the lower pockets the same method.
11. Stitch the front seams of the sleeves and press them open. Fold the sleeve hems to the wrong side and press them.

12. Stitch the front facing to the front centre piece up to the notches showing the collar position. Stitch the lower edges of the front facings to the centre front piece according to the hem fashion line. Trim the seam allowances on the corners and turn the front openings right side out. Edgestitch 0,2 cm in along the center edges. Join the front and back facing across the shoulder seams. Press the seams open
13. Stitch the top collar piece to the neckline. Stitch the under collar to the back/front facing.
14. Fix the epaulets to the shoulders. Stitch the sleeves to the armholes according to the notches.
15. Stitch the underlining seams leaving a hole in front seam of the right sleeve. Stitch the underlining to the raw edge of the front/back facings. Press the collar seams open and fix the seam allowances together close to the seams.
16. Stitch the underlining to the garment. Turn the coat inside out. Pin the side seams of the underlining together with the side seams of the coat and cut accurately along the vent edges moving 1 cm from the centre seam. Make a diagonal cuts 1cm from the top of the vent then fold the lining slit edges inside and pin them to the edges of the vent. Put hand between the coat and the lining take the pinned edges and pull them out. Stitch the corner of the lining at the top end of the vent to the vent seam allowance.
17. Fix the upper parts of the poppers on the flaps; fix the bottom parts on the pockets according to the mark. Fix the upper parts of the poppers on the right centre piece and fix the bottom parts on the left centre piece according to the marks.

TECHNICAL DRAWING:

