

## Sewing Pattern — Jacket 5336

Recommendations on fabric: wool, crepe

You will also need: fusible interfacing, 3 fasteners, lining

If the pattern has a double line around it, the seam allowances are included.

**Note:** By default, seam allowances are NOT included (single line) and will need to be added when laying out and cutting details.

Seam allowance: 1 cm for all seams; 3.5 cm for hem

Attention! First of all, please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to take into account pieces to be duplicated or cut on a fold.

When sewing the garment, pay attention to notches. They must match up with corresponding pieces.



### **CUTTING:**

The word, “beam” used on some patterns means “straight of grain”. Some pieces will be cut on the fold, this is noted on the pattern piece. Mark all notches and other design features such as darts, pleats etc. from the pattern onto your fabric.

Darts: The fold of the dart is always pressed toward the center of your garment, or down toward the hem.

### **Fabric:**

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Center front – cut 2
5. Front facing – cut 2
6. Collar – cut 2
7. Upper sleeve – cut 2
8. Lower sleeve – cut 2
9. Lower sleeve facing – cut 2
10. Upper sleeve facing – cut 2

### **Lining:**

1. Center back – cut 2
2. Side back – cut 2
3. Side front – cut 2
4. Center front – cut 2

7. Upper sleeve – cut 2
8. Lower sleeve – cut 2

### **INSTRUCTIONS:**

1. Apply fusible interfacing to the wrong side of the front facings, sleeve facings, hem seam allowances.
2. Pin collar right sides together and sew outer edge. Clip into curves, trim corners, turn right side out and press.
3. Pin front facing to center front edges, right sides together, and sew. Sew the front facing lower edges to the front strictly along the marked hemline. Trim corners, understitch, turn onto the wrong side of garment, and press.
4. Sew back center seam, press the seam open.
5. Sew the side/shoulder seams, press them open.
6. Sew the outer collar to the neckline. Sew the front facing to the lower edge of the inner collar.
7. Sew the sleeve elbow seams to the notches, and press open. Sew the facing side seams up to the notches, and press open. With right sides together, sew the lower/front sleeve seam with the facing in one continuous stitch. Press the front sleeve seams open. Trim the corners; turn the facings onto wrong side of garment. Press.
8. Make a gathering stitch along sleeve cap for ease. Sew the sleeves to the armholes, matching notches and adjusting ease. Attach sleeve heads and pads to the garment.
9. Sew the lining to the shoulder/side edges of the front facing and to the inner collar. Press the neckline seams open and fix the allowances together. Sew the lower edges of the sleeve lining to the sleeve, and lower edge of lining to the jacket lower edge. Turn the jacket right side out through the sleeve slit. Sew the slit.
10. Attach the decorative fasteners to the front according to marks.

### **TECHNICAL DRAWING:**

