

## Sewing Pattern — Lace top 5302

Recommendations on fabric: lace; silk.

You will also need: satin lining.

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.

Seam allowance: 1 cm for all seams

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



### **CUTTING:**

Fabric:

1. Cups– 2 details
2. Lace cup – 1 detail
3. Basque – 2 details

Lining:

1. Cups – 2 details

Cut pipings of 0.5 cm width by diagonal.

**RECOMMENDATIONS ON SEWING SHEER MATERIAL.** Do not draw contours via carbon paper on material, for they will be visible on the right side. The simplest way is to cut all details with equal allowances and sew edges on equal width.

## **INSTRUCTIONS:**

1. Sew bust darts into cups.
2. Sew bust darts into lining cups.
3. Sew fabric cups.
4. Sew lining cups.
5. Overstitch fabric cups lower edge with lining cups.
6. Sew lace cups to basque with hidden stitches.
7. Tack lining and lace details and then sew them as usual (as lace only).
8. Overstitch lace cups front edges with lining cups, then turn cups into right side.
9. Fold pipings for armhole and back neckline along the center and press. Sew folded pipings to armhole edges, piping bent is on the garment on 0.75 cm width. Cut seam allowances to 0.5 cm width. Turn pipings into wrong side, then topstitch the top along armhole and back neckline.

## **TECHNICAL DRAWING:**

