

Sewing Pattern — Jacket 4203

Recommendations on fabric: natural / mixed thin costume fabric

You will also need: fusing; lining; decorative piping; lace; decorative tape of 2.5 – 3 cm width; separable zipper; shoulder pads, sleeve heads

If the pattern has double contour the seam allowances are included.

Seam allowances are NOT included by default and need to be added when laying out and cutting details if your pattern has single contour.



Seam allowance: on hem and sleeve edge – 3 cm; other seams - 1 cm.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.

CUTTING:

Main fabric:

1. Central back part – 2 details
2. Side back part – 2 details
3. Lower back part – 1 detail
4. Central front part – 2 details
5. Side front part – 2 details
6. Lower front part – 2 details
7. Upper sleeve part – 2 details
8. Lower sleeve part – 2 details
9. Front neckline facing – 2 details
10. Central back part neckline facing – 2 details
11. Side back part neckline facing – 2 details

Lining:

1. Central back part – 2 details
2. Central front part – 2 details
3. Side back part – 2 details
4. Side front part – 2 details

5. Upper sleeve part – 2 details
6. Lower sleeve part – 2 details
7. Lower front part – 2 details
8. Lower back part – 1 detail

Lace:

1. Side back part – 2 details
2. Side front part – 2 details
7. Lower front part – 2 details
8. Lower back part – 2 details

Fusing: central front part, back part neckline facing, buttonstand, sleeve hem

INSTRUCTIONS:

1. Apply fusing to details . Cut depth of darts in the center. Insert decorative tape and sew.
2. Put lace details on lower and side parts of jacket and fix with a stitch on contour on 0.5 cm off the edge.
3. Sew relieve edges on back part, inserting decorative tape between details. Press seam allowances towards center. Sew middle edge of back part. Press seam allowance apart.
4. Sew relieve edges on front part, inserting decorative tape between details. Press seam allowances towards center.
5. Stitch lower part of jacket. Press the seam apart.
6. Sew and press apart side and shoulder edges of jacket.
7. Topstitch decorative tape from two sides, laying on connecting seam of lower parts.
8. Sew and press apart elbow sleeve seam. Press hem of sleeve. Sew and press apart front sleeve seam. Sew sleeves into armholes according to notches, gathering slightly on rounded part. Sew in shoulder pads, sew sleeve heads.
9. Sew in zipper, inserting decorative tape between zipper and buttonstand, starting from the connecting seam of lower parts.
10. Sew seams on lining details and sew in sleeves, leaving a slit in front right seam of sleeve. Sew facings of back part. Press seam allowances apart. Sew shoulder seams of buttonstands and facings. Press the seam apart. Stitch lining to buttonstands and facing. Stitch lower parts of lining.
11. Put buttonstand onto right side of front part right side downwards, pin together and overstitch along buttonstand, along neckline and hem. Turn buttonstands onto right side, straighten seams. Fix seam allowances of lower parts of top part and lining connection seam with a machine stitch or with hand stitches. Turn jacket out through the slit. Sew slit.
12. Sew decorative bow to one side of jacket.

TECHNICAL DRAWING:

