

Sewing Pattern — Jacket 5275

Recommendations on fabric: jersey

You will also need: fusing; 1 separable zipper (depending on front part's length); elastic cord for the hood; 2 caps for cord.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

SEAM ALLOWANCE: 1 cm for all seams, 2.5 cm for garment/sleeve hems and hood's edge.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.

CUTTING:

Fabric:

1. Front part – 2 pieces
2. Back part – 1 piece
3. Sleeve – 2 pieces
4. Side part – 2 pieces
5. Hood – 2 pieces
6. Hood center part – 1 piece
7. Front band – 2 pieces
8. Sacking – 4 pieces
9. Off-set welt – 2 pieces

ADVICE: to prevent seam from stiffing, sew details with special (zig zag) stitch. To prevent hem from stiffing neaten it with overlock and then stitch using double needle. Do the same for all edges which must stay elastic.

The above is not for industrial manufacturing.

INSTRUCTIONS:

1. Apply the fusing to wrong side of off-set welt and press the welt along the center. Fold sackings right sides together, insert the welt between them and stitch the edge of pocket entrance. Turn sackings right side out and press them.

2. Lay ready patch pocket on side part in accordance with marking. Stitch side part to front part inserting patch pocket with the welt. Topstitch joining seam. Stitch shoulder edges together. Stitch side seams. Stitch sleeves. Stitch sleeves into armholes. Stitch hood details together. Neaten



buttonholes into the hood according to marks. Fold the allowance under and topstitch it along hood's front edge. Stitch the hood into neckline.

3. Lay the zipper on edging right sides together (teeth are from edging). Overstitch edging with front bands inserting the zipper. Overstitch the neckline with facing and topstitch it along shoulder seam.

4. Press garment/sleeve hems under and topstitch hems.

5. Press ready jacket.

6. Pull the cord into the hood.

TECHNICAL DRAWING:

