

Sewing Pattern — Gown 5260

Recommendations on fabric: natural or artificial material
150cm. in width.

If the pattern has double contour the seam allowances are included.

If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out and cutting details.

Attention! First of all please print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm) to see how much fabric you will need. Don't forget to count pair parts and symmetrical parts.

When sewing the garment, pay attention to notches, they must coincide.



CUTTING:

Fabric:

1. Patch pocket – 2 pieces
2. Back - 1 folded piece
3. Front - 2 pieces
4. Collar – 2 pieces
5. Belt – 1 piece
6. Sleeve – 2 pieces

INSTRUCTIONS:

1. Fold the pocket integrated facing to the right side and stitch the side seams. Turn it right side out. Press the seam allowances to the wrong side according to the pocket pattern. Edgestitch the pocket top edge. Topstitch the pocket to the garment.
2. Stitch the front darts. Press them downwards.
3. Stitch the side seams up to the slit's marks and press them open.
4. Make up and shape the collar.

5. Press the integrated facings to the right side of the garment front along the marked center front foldline placing the collar between. With right sides together stitch the under collar to the garment neck edge between the shoulder seams, keeping the top collar out of the way. With right sides together stitch the top collar on the previously made seam.
6. Stitch the sleeve seams. Stitch the sleeves to the garment.
7. Fold hem/slit seam allowances to the wrong side of the garment and topstitch them.
8. Make up and topstitch the belt.

TECHNICAL DRAWING:

