

Asymmetrical Dress - Sewing Pattern #2060

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; dress zipper.

Seam allowances: all seams 1 cm. Seam allowance along hem of garment and hem of sleeve - 3.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 2
2. Upper front - cut 1 on fold
3. Side front - cut 2
4. Lower front - cut 1
5. Sleeve - cut 2
6. Back neck facing - cut 2
7. Front neck facing - cut 1

Fusible interfacing:

1. Back neck facing - cut 2
2. Front neck facing - cut 1

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew shoulder and waist darts on back, press bulk towards center. Apply fusible interfacing to vent area on backs from the wrong side. Serge center back edges separately. Serge seam allowances of vent. Mark center seam line (vent fold-line) from the right side. Press left part along vent fold, on the right side press onto wrong side only the seam allowance of right side of vent (1 cm). Align pieces along center seam and baste together along upper edge of vent. Sew center back seam from zipper marker down to vent corner. Clip into seam allowance of vent in corner on right part. Press apart center seam, press seam allowances of the vent and sew them together by machine. Sew in zipper.
3. Sew front darts on upper front, press bulk towards top.
4. Make and baste pleats on lower front (fold bulk towards bottom). Sew upper front to lower front, press towards top and serge.
5. Sew side front to center front, press towards center and serge.
6. Sew side and shoulder seams, press seams towards back and serge.
7. Sew shoulder seams of neck facings, press seam apart. Serge outer edge. Pin facing to garment right sides together and sew the neckline. Fold facing onto wrong side, straighten, press. Slipstitch facing to shell along shoulder seams, slipstitch to zipper tape.
8. Sew sleeve seam, serge and press. Sew sleeve into armhole, matching notches, serge and press.
9. Serge hem of garment and lower edge of sleeve, press onto wrong side and topstitch.

TECHNICAL DRAWING:

