

Short Coat - Sewing Pattern #2090

Recommendations on fabric: natural/mixed fabric suitable for coats.

You will also need: lining; fusible interfacing; 4 buttons; shoulder pads; sleeve heads.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 3.5 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back – cut 2
2. Back yoke – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2
7. Center front facing – cut 2

8. Back neck facing – cut 1

Fusible interfacing:

1. Center front – cut 2
2. Center front facing – cut 2
3. Back neck facing – cut 1
4. Lining of hidden button panel – cut 1

Lining:

1. Back lining – cut 2
2. Front lining – cut 2
3. Upper sleeve – cut 2
4. Lower sleeve – cut 2
5. Pocket bag – cut 2
6. Lining of hidden button panel – cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew center back seam, press seam apart. Sew yoke to back, press seam allowances towards yoke.
3. Pin pocket bag onto front right sides together and sew pocket opening. Fold pocket bag onto wrong side, press.
4. Pin front at front side and sew princess seams and edges of pocket bags with one continuous seam.
5. Sew side and shoulder seams, press seam apart. Sew center collar seam, press seam apart. Sew one-piece collar into neckline, clipping into seam allowance near corner. Clip seam allowances and press apart.
6. Mark closure slit with three lines, on the right side of right button stand (centre front facing). The first line should be parallel to vertical edge of closure and runs at 1.5 cm from the edge when ready, the second and third line mark the length of closure. Pin lining (should be with fusible interfacing applied!) onto the centre front facing, right sides together, matching the edge of lining with the marked line. Stitch at 0.5 cm from the marked line along the closure slit up to the lines that mark the closure length. Pin the second closure lining, matching its edge with the stitched line, and stitch at 0.5 cm. Check if the stitches are parallel on the wrong side. Cut the slit. Clip into corners at 1.5 cm from the closure ends. Turn the linings onto wrong side through the resulting opening, making a slit frame, which equals the distance between stitch lines. Sew a fixing stitch in the ditch of the lining seam. Press the second lining towards inner edge of centre front facing and sew a fixing stitch at 0.1 cm from the lining seam. Mark and make buttonholes. They are made on centre front facing and interfaced lining. Straighten the ends of closure and fix them from the wrong side, with double stitch at the base of corners. Sew edges of lining. Make short fastening stitches between each pair of buttonholes, the length of the fixing stitch equals the width of the frame. Press center front facing.

7. Sew side seams of center front facings and back neckline facings, press seam apart. Sew center collar seam, press seam apart. Sew one-piece collar into neckline, clipping into seam allowance near corner. Clip seam allowances and press apart.
8. Pin center front facings to Shell right sides together and sew center front edges collar edge and lower corner of front. Clip into curves, trim away corners, turn pieces right side out. Sew a decorative stitch along front edge and collar at 0.5 – 0.7 cm.
9. Sew elbow seam on sleeve, press seam apart. Press hem of sleeve. Sew front seam on sleeve, press seam apart. Sew sleeves into armholes matching notches. Sew shoulder pads and sleeve heads.
10. Sew seams on lining and sew in sleeves, leaving a technical opening in the right front sleeve seam. Press seam allowances of lining.
11. Sew lining to buttonstands and facing, press seam. Turn garment right side out, straighten seams.
12. Mark and press onto wrong side seam allowance along hem. Sew lining to lower edge. Turn garment right side out through the opening in sleeve. Sew lining to lower edge of sleeve. Sew the opening closed.
13. Sew on buttons on left front.

TECHNICAL DRAWING:

