

## Long Jeans Jacket - Sewing Pattern #2110

Recommendations on fabric: stable natural/mixed cotton fabrics suitable for outdoor jackets. Denim.

You will also need: fusible interfacing; decorative cord; 2 cord end caps; 12 push buttons.

Seam allowances: all seams 1 cm. Seam allowance of the upper edge of patch pocket – 3 cm.

### Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

### Note on length of fabric:

*Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.*



## CUTTING:

### Note on cutting:

*On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.*

*When sewing the garment, pay attention to notches, they must match up.*

Main fabric:

1. Back – cut 2
2. Front – cut 2
3. Upper sleeve – cut 2
4. Lower sleeve – cut 2
5. Front placket – cut 2
6. Hood – cut 2

7. Center hood – cut 1
8. Hood facing – cut 1
9. Patch pocket – cut 2
10. Flap – cut 2
11. Cuff – cut 2
12. Casing – cut 1
13. Hem facing – cut 2

Fusible interfacing:

1. Front placket – cut 2
2. Hood facing – cut 1
3. Flap – cut 2
4. Cuff – cut 2
5. Hem facing – cut 2

## INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew and press darts on the patch pocket. Apply a strap of fusible interfacing along the upper seam allowance of pocket, press towards 1 cm, then again at 2 cm and topstitch. Press the curved seam allowance onto the wrong side. Topstitch pocket onto front according to markings.
3. Sew the center back seam, press towards left, serge and topstitch 0.5 – 0.7 cm from seam.
4. Sew shoulder and side seams, press towards the back and serge.
5. Sew center seam of facings of hem facings, press the seam apart. Press upper seam allowance facings onto wrong side. Pin facing to garment right sides together and sew lower edge. Clip seam allowances, turn facing onto wrong side. Topstitch the facing onto Shell.
6. Sew outer edge of placket to front, press seam allowances at placket. Turn under the edge of inner placket and topstitch into seam of. Sew a decorative stitchline at 0,1 – 0,2 cm from the edge plackets and from seam.
7. Pin together flap in half lengthwise right sides together and sew side edges. Trim away corners, turn the flap right side out, straighten, press. Sew a decorative stitch at 0.5 – 0.7 cm from the edge. Serge upper edge. Sew flap to front, fold down and topstitch.
8. Serge seam allowances of the shorter edges of casing, press onto wrong side and topstitch. Fold seam allowances of the longer edges of casing onto wrong side and press. Pin the casing onto the right side of the garment according to markings and topstitch.
9. Sew side hoods to center hood, press seam allowances towards center part, serge. Sew a decorative stitch at

0,5 - 0,7 cm from seam.

10. Fold under the inner seam allowance of the hood facing and press. Pin facing onto hood right sides together and sew the outer edge. Clip seam allowances.

11. Sew hood into neckline, placing the neckline edge between the hood and the facing. Press seam, serge. Fold the facing onto the wrong side, topstitch at hood.

12. Serge the edges of the upper sleeve seam separately. Sew upper seam from the sleeve cap up to the notch. Press seam allowances towards the upper part of the sleeve, serge and topstitch at 0,5 - 0,7 cm from seam. Sew lower the sleeve seam, serge and press. Sew sleeves into armholes, serge and press.

13. Fold cuff in half lengthwise, right sides together and sew short sides. Start stitching exactly at the line which marks the seam between cuff and sleeve. Turn cuff right side out and press. Sew outer side of cuff to lower edge of sleeve. Fold inside inner side of cuff and topstitch into seam of.

14. Install push buttons on the front placket, cuffs and flaps. Thread cord into casing, attach cord ends.

## **TECHNICAL DRAWING:**

