# Dress With Bow - Выкройка #2113

Recommendations on fabric: natural/mixed fabrics with elastane suitable for dresses.
You will also need: dress zipper.



Seam allowances: Seam allowance for hem of garment – 2.0 cm, other seams – 1 cm.

**О припусках на швы::**
*- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.*
*- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.*

**О требуемой длине ткани:**
*Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.*

**О работе с эластичными тканями:**
*Детали выкройки из трикотажа стачиваются специальным эластичным швом или швом зигзаг. Припуск на подгибку низа может быть настрочен двойной иглой для сохранения эластичности. Детали также можно стачать при помощи оверлока. При стачивании оверлоком, пожалуйста, обрежьте припуски на швы до ширины 0.6 - 0.8 см.*

## РАСКРОЙ:

**Обратите внимание при раскрое:**
*Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.*
*При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.*

Main fabric:
1. Upper back - cut 2
2. Upper front - cut 1
3. Yoke 1 – cut 1

4. Yoke 2 – cut 1
5. Lower back – cut 2
6. Lower front – cut 1 on fold
7. Facing yokes 1 – cut 1
8. Facing yokes 2 – cut 1
9. Strap – cut 1

## Инструкции:

1. Sew darts on back. Press darts towards center.

2. Make and baste pleats on lower back. Fold bulk towards center. Sew upper back to lower back. Serge seams and press towards top. Serge center edges separately. Sew center edge from notch for zipper to bottom. Press the seam apart. Sew in zipper.

3. Sew bust and waist darts on front. Press bulk of bust darts towards top, press bulk of waist darts towards center.

4. Serge vertical edges of yoke facing 1. Pin facing to yoke 1 right sides together and sew upper and lower edges. Clip into seam allowance near the notch, turn facing right side out. Serge vertical edges of yoke facing 2. Pin facing to yoke 2 right sides together and sew upper and lower edges. Clip into seam allowance near the notch, turn facing right side out.

5. Pin yoke 1 onto front, right sides together (the shoulder edge of yoke is directed towards bottom) and topstitch along the marked line. Fold the yoke towards top, baste to front along raw edges. Treat as one piece in the future. Pin yoke 1 onto front, right sides together (the shoulder edge of yoke is directed towards bottom) and topstitch along the marked line. Fold the yoke towards top, baste to front along raw edges. Treat as one piece in the future. Sew ends of yokes together, press the seam apart and serge.

6. Fold strap in half lengthwise right sides together and sew. Turn the piece right side out, press, placing seam in the middle of the piece. Pin strap onto front, sew it to neckline edge (the piece is placed under the yokes).

7. Sew right shoulder seam, press towards the back and serge. Cut or use ready-made bias tape, its width should equal 4 cm for finishing the neckline. Fold bias tape in half lengthwise right side out and press. Pin bias tape to neckline from the right side and sew, fold the bias tape onto wrong side and topstitch onto main piece along the fold. Sew left shoulder seam, press towards the back and serge.

8. Strap fold towards top, adjust width, making pleats on yokes, and sew to the neckline from the wrong side.

9. Make and baste pleats on lower front. Fold bulk towards center. Sew upper front to lower front. Serge seams and press towards top.

10. Cut or use ready-made bias tape, its width should equal 4 cm for finishing armhole. Fold bias tape in half

lengthwise right side out and press. Pin bias tape onto armhole edge from the right side and sew, fold the bias tape onto wrong side and topstitch onto main piece along the fold.

11. Sew side seams, press towards the back and serge.

12. Serge the lower edge of garment, press onto wrong side and topstitch.

## Технический рисунок:

