

Knit Dress With Draping - Sewing Pattern #2123

Recommendations on fabric: well draping natural/mixed knit fabric of medium stretchiness.

You will also need: 3 buttons.

Seam allowances: all seams 0.7 cm. Seam allowance for hem of garment and hem of sleeve - 2 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.



Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

- 1. Back cut 1 on fold
- 2. Front cut 1
- 3. Collar cut 1
- 4. Sleeve cut 2
- 5. Flap cut 1
- 6. Underlay piece cut 1



INSTRUCTIONS:

- 1. Sew darts on front, trim away seam allowances with serger. Make and baste pleats according to markings. Flap pin together in half lengthwise right side out and press. Sew flap to front, clipping into corners on front. Start and stop stitching exactly according to marked line of pocket opening. Press false pocket.
- 2. Pin underlay piece under flap. Serge along three inner edges underlay piece, front and flap at the same time.
- 3. Sew darts on back. Trim bulk with serger and press towards the center.
- 4. Sew shoulder seams. Serge seams and press towards back. Sew collar into a ring, press the seam allowances apart. Fold collar in half lengthwise and press. Sew collar into neckline. Serge.
- 5. Sew sleeve into open armhole.
- 6. Sew side seams, sewing the sleeve edges at the same time. Attention: make sure that the flap fold doesn't get under the side seam. Serge seams and press towards back.
- 7. Serge hem of garment and lower edge of sleeve. Press seam allowance on lower edge onto wrong side and topstitch.
- 8. Sew on buttons at flap.

TECHNICAL DRAWING:



