

Jacket With Patched Pockets - Sewing Pattern #2139

Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; 4 buttons; buckle.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2.5 cm. Seam allowance along upper edge of pocket – 2 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Center front facing – cut 2
6. Lower collar - cut 1
7. Upper collar – cut 1

8. Back neck facing – cut 1
9. Sleeve – cut 2
10. Cuff – cut 2
11. Pocket welt – cut 1
12. Flap – cut 4
13. Pocket – cut 2
14. Pocket placket – cut 2
15. Belt Loop – cut 1
16. Belt – cut 1

Lining:

1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
3. Sleeve – cut 2

Attention! Front and back from lining are cut using the pattern blocks for self fabric, with the exception for the areas of center front facing and back neckline facing.

Fusible interfacing:

1. Center front – cut 2
2. Center front facing – cut 2
3. Back neck facing – cut 1
4. Upper collar – cut 1
5. Pocket welt – cut 1
6. Flap – cut 2
7. Belt – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusing on front along the lapel fold , its width should equal 1 cm (fusible interfacing).
2. Sew side backs to center back, press the seam apart. Sew the center back seam, press the seam apart.
3. Sew side fronts to front, press the seam apart.
4. Fold off-set welt in half lengthwise right sides together and sew along shorter edges. Trim away corners, turn the piece right side out, press. Pin off-set welt onto front along the lower marking line (the fold is directed towards bottom) and sew. Fold off-set welt upwards, press, topstitch side edge onto front.
5. Sew the pocket placket to the pocket along the side edges and the lower edge. Serge. Sew the seam

allowance along the lower edge of the placket. Fold the upper seam allowance of the pocket and the placket onto wrong side, then fold it under the second time and topstitch. Fold under the side seam allowances and the lower seam allowances of the pocket placket, and press. Pin pockets onto fronts according to markings and topstitch. Pin together flaps right sides together and sew. Trim seam allowances at the corners клапанов and turn right side out. Швы straighten and press. Sew a decorative stitch on flap at 0.2 cm. from the edge. Sew flaps to fronts, fold down and topstitch.

6. Sew and press apart shoulder and side edges.

7. Pin upper collar to lower collar and sew the corners and the outer edge. Start and stop sewing exactly at the marked line of the seam between collar and garment. Trim away corners, snip into seam allowance near the mark. Turn the collar right side out, straighten and press.

8. Sew and press apart the shoulder edges of the back neckline facing and of the center front facing.

9. Place center front facing onto front right sides together, pin together and sew along the center front edge. Sew upwards up to the notch marking the end of collar seam. Trim away corners. Topstitch seam allowance along center front edge onto center front facing along the closure, and onto front along the part, which is folded away. Place stitch line at 0,2 cm from seam. Turn center front facings right side out, straighten seams.

10. Sew lower collar into neckline of jacket, sew upper collar into neckline of back facing and center front facing. Press seam allowances of the collar seam apart and slipstitch them together close to the seam.

11. Sew sleeve seam, press the seam apart. Sew sleeves into armholes matching notches.

12. Serge one longer edge of the belt loop. Fold belt loop so that it has 3 layers in total and topstitch along longer sides. Cut the belt loop in 2 parts. Topstitch the belt loop onto jacket onto the side seams.

13. Sew seams on lining and sew in sleeves.

14. Sew lining to inner edges of the central front facings and to back neckline facing. Sew lining to hem of jacket. Turn jacket right side out through the sleeve. Make and baste pleats along the lower edge of the sleeve. Sew cuff into a ring. Press the seam apart. Fold cuff in half lengthwise and press. Sew the outer side to the sleeve. Press towards cuff. Fold under the seam allowance of the inner side and stitch-in-the-ditch into the connecting seam.

15. Fold belt in half lengthwise right sides together and sew around all edges, leaving an opening. Trim away corners, turn right side out and press. Sew the opening closed. Sew a decorative stitch around all edges at 0.5 cm from the edge. Attach the buckle to the belt end.

16. Make buttonholes on right front, sew on buttons onto left front.

TECHNICAL DRAWING:

