Hoodie With Patch Pocket - Sewing Pattern #2175

Recommendations on fabric: Fleece, soft thick knit fabric (footer).

You will also need: rib knit fabric or knit fabric of high stretchiness; knit fusible interfacing; cord for hood; separating zipper; cord ends.



Seam allowances: Seam allowance along hem center front facings – 0 cm; Seam allowance of outer edge of hood 2 cm. Seam allowance along pocket opening – 2 cm. All other seams 1 cm.

Note on seam allowances:
- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:
Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

Note on working with stretchy fabric:
Knitted fabric pieces are sewn together with special elastic or narrow zig-zag stitch. Seam allowance on hems can be stitched with twin needles to save stretchiness. Pieces can also be sewn together with a serger. When serging, cut seam allowances to 0.6 – 0.8 cm.

CUTTING:

Note on cutting:
On the pattern pieces, “beam” means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.
When sewing the garment, pay attention to notches, they must match up.

Main fabric:
1. Front – cut 2
2. Back - cut 1 on fold

3. Sleeve - cut 2
4. Patch pocket – cut 2
5. Hood – cut 2
6. Center front facing – cut 2
7. Back neck facing – cut 1

Main fabric 1:
1. Hem facing – cut 1
2. Cuff – cut 2

Fusible interfacing:
1. Center front facing – cut 2
2. Back neck facing – cut 1

INSTRUCTIONS:

1. Apply fusible interfacing. Apply fusible interfacing to the area of button holes and to the slanted edge of the pocket.

2. Sew darts on front, if the size implies these.

3. Serge pocket opening. Fold inside the seam allowance and topstitch. Serge upper, lower and side edges of the pockets and fold them under and press. Mark the position of pocket on front and topstitch pocket.

4. Sew shoulder edges of the sweatshirt. Press towards back and serge.

5. Sew sleeve into open armhole. Serge the seam. Sew side edge and sleeve edge. Serge the seam and press towards back.

6. Fold the facing in half lengthwise wrong sides together and press. Sew the facing to the hem, slightly stretching the facing. Serge and press.

7. Sew hood seam. Serge seam and press towards left. Make buttonholes. Serge outer edge of hood, fold onto wrong side and topstitch, making a casing. Sew hood into neckline.

8. Sew shoulder edges of center front facing and of the back neckline facings. Press the seam apart. Serge outer and lower edges center front facings and facings. Pin center front facing onto Front, adjust edges, insert the zipper, and sew along the neckline and center edge. Fold away center front facing onto wrong side and baste together along shoulder edge. Slipstitch the lower edge of center front facing to the seam of lower placket. Sew a decorative stitch along the zipper.

9. Sew cuff into a ring, press the seam apart. Fold cuff in half lengthwise right side out and press. Sew cuff to lower edge of sleeve, slightly stretching it. Serge and press.

10. Insert cord into casing, attach cord ends.

TECHNICAL DRAWING:

