

Short Jacket - Sewing Pattern #2241

Recommendations on fabric: natural/mixed suiting or light coat fabrics.

You will also need: lining; fusible interfacing; separating zipper; shoulder pads.

Seam allowances: Upper seam allowance of pocket - 2 cm. All other seams 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.



Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.

CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Front - cut 2
2. Back - cut 1 on fold
3. Sleeve - cut 2
4. Pocket - cut 2
5. Flap - cut 4
6. Center front facing - cut 2

7. Back neck facing – cut 1
8. Collar – cut 2
9. Hem facing – cut 1 on fold
10. Cuff – cut 2

Lining:

1. Front – cut 2
2. Back – cut 1 on fold
3. Sleeve – cut 2

Fusible interfacing:

1. Center front facing – cut 2
2. Collar – cut 1
3. Back neck facing – cut 1
4. Cuff – cut 2
5. Flap – cut 2
6. Hem facing – cut 1

Attention: front and back from lining are cut using the pattern clocks for the main fabric except for the width of center front facing and back neckline facing.

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Serge upper edge of pocket. Fold seam allowance inside and topstitch. Serge and fold inside lower and side seam allowances of pocket onto wrong side and press. Mark the position of pocket on front and topstitch pocket. Pin together flaps, right sides together, and sew along side and lower edges. Trim seam allowances, turn right side out and press. Sew a decorative stitch along all edges of the flap. Pin flap onto front according to markings, seam allowance is directed towards bottom and topstitch. Fold flap down and sew a fixing stitch.
3. Sew shoulder and side seams. Press seams apart.
4. Sew sleeve seam. Press towards back. Sew sleeve into armhole. Seam Allowance press. Sew on shoulder pads. Sew cuff into a ring, press seam apart. Fold cuff in half lengthwise right side out and press. Sew outer side of cuff to sleeve.
5. Sew lower collar into neckline. Clip seam allowances and press apart.
6. Sew lower placket to the jacket. Press seam apart.
7. Sew zipper to jacket.

8. Sew seams on lining, leaving an opening in left sleeve.
9. Sew shoulder seams facings and center front facings. Press seam apart. Sew upper collar into neckline , clip seam allowances and press apart. Sew facing and center front facing to lining, press seam allowances towards lining. Sew lining to the inner edge of lower facing, press towards facing.
10. Pin lining to the garment right sides together. Sew center front facings and collar. Trim away of seam allowances on the corners of collar. Turn the jacket right side out through the opening. Slip stitch collars together close to the seam. Stitch in the ditch into the seam of lower placket, connecting main fabric to lining.
11. Sew lining to cuff. Slipstitch seam allowances of main fabric and lining together.
12. Sew the opening closed.
13. Sew decorative stitch along the center front edge and around all edges of collar.

TECHNICAL DRAWING:

