

Double Breasted Coat - Sewing Pattern #2250

Recommendations on fabric: natural or mixed soft thin stable fabric suitable for coats.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve - 3.0 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 2
3. Sleeve - cut 2
4. Center front facing - cut 2
5. Back neck facing - cut 1
6. Pocket bag - cut 4

7. Belt – cut 1

INSTRUCTIONS:

1. Sew darts on front. Press bulk towards bottom.
2. Pin pocket bag onto the right side of Front, topstitch pocket opening around all edges. Slash openings in the pieces in between the stitch lines, make diagonal cuts, starting at 1 cm from the shorter sides. Turn pocket bag onto the wrong side, straighten pocket opening. Pin the second pocket bag onto the first pocket bag and sew together. Slipstitch pocket bags to the wrong side of Front.
3. Pin fronts right sides together and sew the collar seam, press the seam apart. Sew the shoulder seams and press the seam allowances apart. Clip into seam allowance of shoulder seam on front and sew in the collar into the back neckline, press the seam allowances apart.
4. Sew collar seam center front facings, press the seam apart. Sew shoulder seams of center front facings and back neckline facings, press seams apart. Clip into seam allowance of shoulder seam on the center front facing and sew collar into the neckline of back facing, press the seam allowances apart.
5. Place center front facing onto front right sides together, pin together and sew along the center front edge, collar fall of collar and lower corner. Clip seam allowances, turn center front facing onto wrong side, straighten, press. Sew a decorative stitch along center front edge and collar at 0.5 – 0.7 cm from the edge.
6. Sew sleeves into armholes matching notches, press seam.
7. Sew side seams processing the sleeve seam at the same time, press towards the back.
8. Fold belt in half lengthwise, right sides together, and sew along long side and one short side. Turn belt right side out, turn under the seam allowances of the area that has not been stitched and sew a decorative stitch at 0.5 – 0.7 cm from the edge around the belt.

TECHNICAL DRAWING:

