Blouse With Draping - Выкройка #2251



Recommendations on fabric: natural/mixed well draping blouse fabrics.

You will also need: fusible interfacing; 3 buttons; 2 beads; decorative closure.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 2
2. Front - cut 1
3. Cuff – cut 2
4. Sleeve – cut 2
5. Front neck facing – cut 1
6. Back neck facing – cut 2

Fusible interfacing:
1. Cuff – cut 2
2. Front neck facing – cut 1
3. Back neck facing – cut 2

Инструкции:

1. Apply fusible interfacing.

2. Serge center back seams separately. Sew center edge from the marking for slit down to the lower edge, press the seam apart.

3. Sew a gathering stitch along the left shoulder edge of Front and gather fullness. (most gathers should be close to neckline). Sew shoulder and side seams, press towards the back and serge.

4. Cut (or take ready) bias tape, its width should equal 2.5 cm and its length should equal 10 cm for loop buttonhole. Fold tape in half lengthwise right sides together and stitch at 0.3 cm from fold. Cut away seam allowances close to seam, turn tape right side out and straighten the rolled piece. Adjust length of the loop.
5. Sew the shoulder seams of the neckline facings. Press the seam apart. Serge the outer edge. Pin facing, right side down, onto the right side of blouse and sew neckline and center edge of back, inserting the loop buttonhole. Clip seam allowances, fold facing onto wrong side and press. Slip stitch facing to shoulder seams. Sew a fixing stitch at 0.1 – 0.2 cm from slit edge.

6. Serge the sleeve's edges separately. Sew sleeve seam up to mark for slit, press the seam apart. Sew a fastening stitch along the slit at 0.1- 0.2 cm. Sew sleeves into armholes. Serge the seam allowances.

7. Fold cuff in half lengthwise, right sides together and sew short sides. Trim seam allowances, turn cuff right side out and press. Sew outer side of cuff to sleeve. Fold under the seam allowance of the inner side inside and topstitch.

8. Press lower edge of garment onto wrong side at 1 cm, then again at 1 cm and topstitch.

9. Make buttonholes and sew on buttons at cuffs and neckline.

10. Make pleats as desired across the marking. Fix gathers in place from both sides using the beads, leaving ease of 5-6 cm. You may use grommets and chain.

Технический рисунок:

