

Denim Jacket - Sewing Pattern #2284

Recommendations on fabric: natural/mixed jeans fabrics.

You will also need: fusible interfacing; 7 buttons.

Seam allowances: all seams 1 cm.

Note on seam allowances:

- If the pattern has double contour the seam allowances are included. They are 1 cm unless specified otherwise.
- If the pattern has single contour, the seam allowances are NOT included and need to be added when laying out the pattern.

Note on length of fabric:

Attention! The amount of fabric needed for your pattern is not included. It will depend on the selected pattern size, the width, and design of the fabric you plan to use. First, print all the paper patterns and lay them out at the width of fabric you plan to use (usually from 90 to 150 cm). Measure how much fabric you will need. Don't forget to account for pieces that need to be cut multiple times and pieces that are cut on the fold.



CUTTING:

Note on cutting:

On the pattern pieces, "beam" means straight of grain. Lay out your pieces accordingly. Some pieces will be cut on the fold. This is noted on the pattern piece. Mark all notches and other design features such as pleats etc. from the pattern onto your fabric.

When sewing the garment, pay attention to notches, they must match up.

Main fabric:

1. Upper center back – cut 1 on fold
2. Lower center back – cut 1
3. Upper side back – cut 2
4. Lower side back – cut 2
5. Upper center front – cut 2
6. Upper side front – cut 2
7. Lower side front – cut 2

8. Lower center front – cut 2
9. Stand collar - cut 2
10. Placket – cut 2
11. Upper sleeve – cut 2
12. Lower sleeve – cut 2
13. Cuff – cut 2

Fusible interfacing:

1. Stand collar – cut 1
2. Placket – cut 2
3. Cuff - cut 2

INSTRUCTIONS:

1. Apply fusible interfacing.
2. Sew center upper back to center lower back, press towards top, serge, sew a decorative stitch along the seam at 0.5 cm. Sew side upper back to side lower back, press towards top, serge, sew a decorative stitch along the seam at 0.5 cm. Sew side backs to center back, press towards side seam, serge, sew a decorative stitch along the seam at 0.5 cm.
3. Sew center lower front to center upper front, press towards top, serge, sew a decorative stitch along the seam at 0.5 cm. Sew side upper front to side lower front, press towards top, serge, sew a decorative stitch along the seam at 0.5 cm. Sew side front to center front, press towards side seam, serge, sew a decorative stitch along the seam at 0.5 cm.
4. Sew shoulder and side seams, press towards the back and serge.
5. Cut a bias tape main fabric, its width should equal 4 cm and its length would equal the length of the lower edge. Apply fusible interfacing to the tape. Press upper edge onto wrong side at 1 cm. Pin the strap to the lower edge of garment right sides together and sew. Clip seam allowances, fold the strap onto wrong side and topstitch onto garment along the upper fold.
6. Pin together plackets in half lengthwise right sides together and sew upper and lower corners. Start and stop stitching exactly at the marked line of the placket seam. Turn right side out placket onto right side, straighten, press. Sew outer edge of placket to front, press seam allowances onto placket. Fold the seam allowance of the inner side onto the wrong side and press and topstitch into seam of.
7. Pin together parts of stand collar, right sides together and sew the outer side. Start and stop sewing exactly at the marked line of seam between stand collar and garment. Clip seam allowances. Stand collar turn right side out, straighten and press. Sew outer stand collar into neckline, press seam allowances towards stand collar. Fold the seam allowance of the inner side onto the wrong side and press and stitch in the ditch.

8. Serge the elbow edges of the sleeve separately. Sew the elbow seam of sleeve from the cap to the mark, clip into seam allowance near the notch. Press the seam allowance on the area from sleeve cap to mark and sew a decorative stitch along the seam at 0.5 cm. Press apart the seam allowances on the area from the mark down to hem and sew decorative stitch along the edges at 0.1 cm. Sew and press apart front sleeve seam. Sew sleeves into armholes matching notches.

9. Fold cuffs in half lengthwise right sides together and sew short sides. Start and stop stitching exactly at the marked line of the cuff seam. Turn cuff right side out, straighten and press. Sew outer side of cuff to lower edge of sleeve, press towards cuff. Fold the seam allowance of the inner side onto the wrong side and press and topstitch into seam of.

10. Make buttonholes on right front, sew on buttons on the left one. Make buttonholes and sew on buttons onto cuffs.

TECHNICAL DRAWING:

