Blouse With Wrap Effect - Выкройка #2298

Recommendations on fabric: soft natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 4 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2 cm.



О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 1 on fold
2. Front - cut 2
3. Sleeve – cut 2
4. Cuff – cut 4

Fusible interfacing:
1. Cuff – cut 2

Инструкции:

1. Apply fusible interfacing.

2. Make and baste pleats on the shoulder edges of front (the bulk is directed towards neckline).

3. Sew center collar seam, after having pinned fronts right sides together, press the seam apart. Serge the outer edge of the one piece center front facing.

4. Sew shoulder seams, press towards the back and serge. Clip into seam allowance of shoulder seam on front and sew the outer edge of the collar into the back neckline, press seam allowances towards the collar.

5. Press collar along the marked fold line. Topstitch the inner edge of the collar into the connecting seam. Baste the lower edge of the one piece center front facing to the side edge. Put right front onto left front and baste together along the lower and side edge.

6. Sew side seams, press towards the back and serge.

7. Serge the sleeve edges separately. Sew sleeve seam from armhole up to mark for slit, press the seam apart. Topstitch slit at 0.1 cm from fold. Sew sleeves into armholes, serge and press.

8. Pin cuffs together, right sides together and sew side edges. Start and stop stitching exactly at the marked line of the cuff seam. Turn the piece right side out, straighten, press. Make and baste two pleats along the lower edge of the sleeve. Sew outer side of cuff to sleeve, fold the seam allowance of the inner cuff inward and stitch in the seam attaching the outer cuff.

9. Press lower edge of garment onto wrong side two times at 1 cm and topstitch.

10. Make buttonholes on cuffs, sew on buttons.

Технический рисунок:

