

Blouse With Lace - Выкройка #2352

Recommendations on fabric: natural/mixed fabrics suitable for blouses. Lace with scallops.

You will also need: fusible interfacing; 11 buttons.

Seam allowances: Seam allowance for hem of garment - 2.5 cm; seam allowance along the lower edge of front inset and sleeve inset - 0 cm; other seams - 1 cm.

О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:

Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Back - cut 1 on fold
2. Front yoke - cut 2
3. Lower front - cut 2
4. Upper sleeve - cut 2
5. Lower sleeve - cut 2
6. Placket — cut 2
7. Stand collar - cut 2
8. Cuff - cut 2



Decorative fabric:

1. Front inset – cut 2
2. Sleeve inset – cut 2

Fusible interfacing:

1. Placket — cut 2
2. Stand collar – cut 1
3. Cuff – cut 2

Attention! When cutting front inset and sleeve inset, place the lower edge of the pieces at some distance from the scallops edge for the convenience of sewing.

Инструкции:

1. Apply fusible interfacing.
2. Sew front darts, press bulk towards top.
3. Sew tucks on lower front, folding the piece wrong sides together. Press the bulk towards the center.
4. Sew front yoke to inset, press towards top and serge. Serge upper edge of lower front. Pin front inset onto lower front, matching the marked stitch lines and topstitch.
5. Press placket in half lengthwise right side out. Sew outer edge of placket to front, press seam allowances onto placket. Fold the edge of inner placket under and stitch in the ditch.
6. Sew side and shoulder seams, press towards the back and serge.
7. Pin stand collars together right sides together and sew outer edges. Start and stop sewing exactly at the marked line of seam. Clip into curves. Turn the finished stand collar right side out and press.
8. Sew outer stand collar into neckline, press seam allowances at stand collar. Turn under the unfinished edge of inner stand collar and stitch in the ditch.
9. Sew upper sleeve to inset, press towards top and serge. Serge the upper edge of lower sleeve. Pin front inset onto lower sleeve, matching the marked stitch lines and topstitch.
10. Serge the sleeve edges separately. Sew sleeve seam from armhole up to mark for slit, press the seam apart. Topstitch slit at 0.1 cm from fold. Sew a gathering stitch along the sleeve cap and gather fullness. Sew sleeves into armholes, serge and press. Sew a gathering stitch along lower edge of sleeve and gather fullness.
11. Fold cuff in half lengthwise, right sides together and sew side seams. Turn the piece right side out, press. Sew outer side of cuff to sleeve, fold inside the seam allowance of the inner cuff and topstitch into the seam of

outer cuff.

12. Turn hem under inside at 1 cm, then at 1.5 cm and topstitch.

13. Make buttonholes on right placket and on stand collar, sew on buttons on the left one. Make buttonholes and sew on buttons onto cuffs.

Технический рисунок:

