

Hoodie - Выкройка #2358

Recommendations on fabric: natural/mixed knit fabric of small stretchiness.

You will also need: rib knit fabric or knit fabric of high stretchiness; decorative cord; cord ends for the cord.

Seam allowances: all seams - 1 cm.

О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.

- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:

Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.



РАСКРОЙ:

Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Back - cut 1 on fold
2. Front - cut 1 on fold
3. Sleeve — cut 2
4. Pocket - cut 1
5. Hood - cut 1 on fold
6. Center hood - cut 1
7. Hood facing - cut 1

Main fabric 1:

1. Hem facing - cut 1
2. Cuff - cut 2

Инструкции:

1. Serge the edge of one-piece facing of the pocket opening. Fold under the pocket facing and press and topstitch. Serge the pocket edges. Fold under the side and lower edges and press. Pin pocket to front, right sides together, along the upper marking line of the pocket placement (the lower edge of pocket is directed towards the neckline) and sew. Fold away pocket down. Topstitch pocket onto front along the side edges.
2. Sew sleeve to back, press seam allowances towards sleeve and serge. Sew sleeve to front, press seam allowances towards sleeve and serge.
3. Sew sleeve seam and side seam continuously, press towards the back and serge.
4. Sew center piece to the hood pieces, press seam allowances onto central part and serge. Make button holes for cord. Sew hood into neckline, serge and press.
5. Serge inner edge of hood facing. Pin facing onto hood right sides together and sew the outer edge. Clip into curves, turn facing onto wrong side, press. Topstitch the facing onto the hood, making a casing.
6. Sew cuff into a ring, press the seam apart. Fold cuff in half lengthwise right side out and press. Sew cuff to lower edge of sleeve, slightly stretching it. Serge and press.
7. Sew hem facing into a ring, press the seam apart. Fold facing in half lengthwise wrong sides together and press. Sew facing to hem of garment, placing the seam under the left side seam and slightly stretching it. Serge and press.
8. Thread the cord into hood, attach cord ends.

Технический рисунок:

