Denim Shirt - Выкройка #2391



Recommendations on fabric: natural/mixed jeans fabrics.

You will also need: fusible interfacing; 8 buttons.

Seam allowances: Seam allowance for hem of garment and hem of sleeve – 1.5 cm; other seams – 1 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back - cut 1
2. Front - cut 2
3. Back yoke – cut 1
4. Placket — cut 4
5. Sleeve – cut 2
6. Sleeve decorative tab – cut 2
7. Collar – cut 2

8. Stand collar – cut 2
9. Pocket – cut 2
10. Pocket facing – cut 2

Fusible interfacing:
1. Stand collar – cut 1
2. Placket – cut 2
3. Collar – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew darts on back, press the inner part towards center. Sew yoke to back. Serge and press towards top.

3. Make a box pleat on the pocket and baste it along the lower edge and the upper edge. Fold pocket facing in half lengthwise wrong sides together, and sew it to the upper edge of the pocket. Serge seams and press towards top. Sew a decorative stitch. Turn under the side seam allowances and the lower seam allowance of the pocket and press. Topstitch pocket onto front according to markings.

4. Pin plackets together by two and sew the outer edge. Turn pieces right side out and press. Sew outer placket to front, press seam allowances onto placket. Fold the edge of inner placket under and stitch in the ditch.

6. Sew side and shoulder seams, press towards the back and serge.

7. Pin upper collar to lower collar, right sides together. Sew ends of collar and collar fall. Trim seam allowances. Turn the collar right side out, straighten and press. Sew a decorative stitch at 0.5 cm from the edge. Pin stand collars together, right sides together, put ready collar between them, adjust notches and sew, sewing ends of stand collar at the same time. Start and stop sewing exactly at the marked line of seam between stand collar and garment. Turn finished collar right side out and press. Sew upper stand collar with collar into neckline, fold raw edge of lower stand collar and stitch-in-the-ditch along seam of upper stand collar.

8. Fold decorative tabs in half lengthwise right sides together and sew along longer and one shorter edge. Turn right side out, snipping the seam allowances in corners, straighten and press. Serge the unfinished shorter edge. Topstitch decorative tabs according to the markings onto the wrong side of sleeves.

9. Sew sleeve seams, press towards back and serge. Sew sleeves into armholes, serge and press.

10. Serge hem of garment and hem of sleeve, turn inside and topstitch.

11. Make buttonholes on right front, sew on buttons on the left one. Make buttonholes on decorative tabs, sew on buttons onto sleeves.

Технический рисунок:

