

## Dress With Gathers - Выкройка #2500

Recommendations on fabric: natural/mixed well draping knit fabric of medium or high stretchiness.

Seam allowances: seam allowance for hem of garment, along neckline - 1.5 cm, other seams 0.8 cm.

### О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.

- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

### О требуемой длине ткани:

**Внимание!** В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.



## РАСКРОЙ:

### Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Back - cut 2
2. Front yoke - cut 1
3. Upper front - cut 1
4. Lower front - cut 1
5. Sleeve - cut 2

## **Инструкции:**

1. Sew center back seam. Press towards left and serge.
2. Sew a gathering stitch on upper front along the edge of the future yoke seam and gather fullness. Sew the yoke, press seam allowances towards yoke and serge.
3. Sew a gathering stitch on upper front from the edge of the right armhole up to marking, and gather fullness so that the length matches the length of the corresponding area on lower front, also from the edge of the armhole up to marking. Sew a gathering stitch on lower front from the marking up to side edge, and gather fullness so that the length matches the length of the corresponding area on upper front, also from the marking to side edge. Sew upper front to lower front, serge and press.
4. Sew right shoulder seam, press seam allowances towards back and serge.
5. Cut or use ready-made bias tape, its width should equal 4 cm length should equal the length of neckline + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to neckline from the right side and sew, fold the bias tape onto wrong side and topstitch onto main piece along the fold.
6. Sew left shoulder and side seams, press towards the back and serge.
7. Sew sleeve seam, press towards the back and serge. Sew sleeves into armholes, matching notches, serge and press.
8. Serge the lower edge of garment, press onto wrong side and topstitch.

## **Технический рисунок:**

