

## Dress With Decorative Neckline - Выкройка #2540

Recommendations on fabric: natural/mixed fabric suitable for dresses.

You will also need: lining; fusible interfacing; dress zipper.

Seam allowances: all seams 1 cm; seam allowance for hem of dress - 3 cm; seam allowance along the slit on lower back piece - 2 cm.

### О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.

- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

### О требуемой длине ткани:

**Внимание!** В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.



## РАСКРОЙ:

### Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Upper center back - cut 2
2. Upper side back - cut 2
3. Lower back - cut 2
4. Upper center front - cut 1
5. Upper side front - cut 2
6. Lower front - cut 1 on fold

Lining:

1. Upper center back - cut 2
2. Upper side back - cut 2
3. Upper center front - cut 1
4. Upper side front - cut 2

**Инструкции:**

1. Apply fusible interfacing to the neckline, the décolleté and the armholes.
2. Sew princess seams on upper back, press seam allowances towards center, serge.
3. Sew darts on lower backs, press bulk towards center. Sew upper back to lower back, press towards top and serge.
4. Serge center back edges separately on each piece. Sew center back seam from notch for zipper down to notch for slit, press the seam apart. Sew in zipper. Sew a fixing stitch line along the slit at 0.2 cm from the edge.
5. Sew front darts, press bulk towards top.
6. Pin upper center fronts together main fabric and of lining right sides together and sew upper edge. Trim away corners, turn pieces right side out, straighten, press. Treat as one piece in the future.
7. Pin together the upper side front from the main fabric and the upper side front from lining, insert upper central front in between and sew the princess seam, stopping at 5 cm from the neckline. Turn pieces right side out, straighten, press.
8. Sew darts on lower front, press bulk towards center. Sew upper front to lower front, press towards top and serge.
9. Sew shoulder seams on pieces from main fabric, press the seam apart. Sew side seams on pieces from main fabric, press towards the back and serge.
10. Sew seams on lining, serge and press. Serge lower edge. Pin lining to garment right sides together and sew neckline and the area of the front princess seam that has remained unsewn. Clip into curves, trim away corners. Turn garment right side out. Sew armhole in two steps: first sew the front armhole, then sew the back armhole. Sew by hand the lining to the zipper tape and to the waist seam.
11. Seam allowance for hem serge, press onto wrong side and finish with hidden stitches.
12. Sew the upper side fronts together by hand in the neckline area.

Технический рисунок:

