Blouse With Decorative Placket - Выкройка #2551

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 4 buttons.

Seam allowances: all seams 1 cm. Seam allowance along the lower edge of the garment – 2 cm.



О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back - cut 1 on fold
2. Front – cut 1 on fold
3. Sleeve – cut 2
4. Placket – cut 2
5. Back yoke – cut 1
6. Cuff – cut 2

Fusible interfacing:
1. Cuff – cut 2
2. Placket — cut 2

Инструкции:

1. Apply fusible interfacing.

2. Sew darts on front (if the size implies these). Press bulk towards top.

3. Pin together plackets in half lengthwise right sides together and sew the upper side. Trim away the seam allowance, turn right side out and press. Sew plackets to front along longer edge, leaving the distance of 1 cm away from hem. Snip into seam allowance on front, leaving 1 mm to the stitch line. Pin right placket onto left placket. Sew together ends of plackets, folding away the front and fixing the lower edge. Serge the seam allowances.

4. Serge lower edge of back yoke. Pin back to yoke, right sides together and sew neckline. Trim seam allowances, clip into curves, fold away the yoke onto wrong side and press.

5. Insert the seam allowance of front in between back and yoke, back with yoke to front. Topstitch the lower edge of yoke onto back from the right side.

6. Sew side seams. Serge seams and press towards back.

7. Cut slit on sleeve along the marked line. Cut bias tape from main fabric (or take ready), its width should equal 4 cm and length should equal two lengths of slit +4 cm. Fold bias tape in half lengthwise and press. Press outer seam allowances towards center. Sew bias tape to slit of sleeve (pin bias tape to slit edge from the right side and sew, fold bias tape onto wrong side and topstitch onto garment along fold line). Make and baste the pleat on sleeve. The bulk is directed away from the closure.

8. Sew sleeve seam. Serge and press towards back. Sew sleeves into armholes. Serge and press.

9. Fold cuffs in half lengthwise right sides together and sew side edges. Start and stop stitching exactly at the marked line of the cuff seam. Turn the piece right side out, press. Sew outer side of cuff to sleeve, fold the seam allowance of the inner cuff inward and stitch in the seam attaching the outer cuff.

10. Serge the lower edge of garment. Press onto wrong side and topstitch.

11. Make buttonholes on cuffs. Sew on buttons at cuffs.

Технический рисунок:

