

Dress With False Wrap - Выкройка #2561

Recommendations on fabric: natural/mixed fabrics with elastane suitable for dresses.

You will also need: fusible interfacing, dress zipper; decorative button.

Seam allowances: all seams 1 cm. Seam allowance along lower edge of garment and lower edge of sleeve - 2 cm. Seam allowance along the neckline edge and along the center edge of the decorative piece - 1.5 cm.

Attention: Pattern blocks have markings and texts from the right side. Take this into account when cutting the fabric-some of the pattern blocks need to be laid onto fabric with their wrong side on top.

О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:

Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Back - cut 2
2. Front - cut 1



3. Front neck facing - cut 1
4. Back neck facing - cut 2
5. Sleeve - cut 2
6. Front decorative piece - cut 1

Fusible interfacing:

1. Front neck facing - cut 1
2. Back neck facing - cut 2

Инструкции:

1. Apply fusible interfacing. Apply a strap of fusible interfacing onto the neckline edge and onto the center edge of the decorative piece.
2. Sew darts on back, press the inner part towards center. Serge the center back edges separately. Sew center back seam from notch for zipper to bottom. Press the seam apart. Sew in zipper.
3. Sew darts on front. Press bulk of bust darts towards top, press bulk of waist darts towards center.
4. Sew the dart on the decorative piece. Press bulk towards top. Serge the seam allowance along the neckline, the center edge and the lower edge of the decorative piece. Turn seam allowances inside and topstitch. Pin the decorative front piece onto the right side of front and baste together along the side edges and the shoulder edges.
5. Sew side and shoulder seams. Press seams towards back and serge.
6. Sew shoulder seams of facings. Press the seam apart. Serge the outer edge. Pin facing onto main piece, right sides together and sew neckline. Clip seam allowances, trim away corners, fold facings onto wrong side and press. Slipstitch center seam allowances on facing to zipper tape. Baste together along the shoulder edges.
7. Sew sleeve seam. Serge and press towards back. Sew sleeves into armholes. Serge and press.
8. Serge hem and hem of sleeve. Press onto wrong side and topstitch.
9. Make a buttonhole and sew on a button.

Технический рисунок:

