Blouse With Central Pleat - Выкройка #2594

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 2 buttons.

Seam allowances: Seam allowance for hem of garment – 2.5 cm; other seams – 1 cm.



О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back - cut 1 on fold
2. Front - cut 1 on fold
3. Sleeve – cut 2
4. Lapel — cut 2
5. Back neck facing – cut 1
6. Cuff – cut 2

Fusible interfacing:
1. Lapel — cut 2
2. Back neck facing – cut 1
3. Cuff – cut 2

Инструкции:

1. Apply fusible interfacing.

2. Sew front darts, press bulk towards top.

3. Serge the outer edges of the lapels. Pin lapels to front piece right sides together and sew the outer edge. Clip seam allowances, trim away corners. Also snip seam allowance in the corners near the pleat on the front piece , serge the seam allowance of the front piece. Turn lapels onto the wrong side, straighten, press. Make a pleat, matching center lines. Sew a stitch line along the top of the pleat to fix it.

4. Serge outer edge of back neckline facing. Pin neckline facing onto Back and sew neckline exactly up to the marked line of shoulder seam. Clip seam allowances, fold facing onto wrong side and press.

5. Sew shoulder seams, inserting the Front between the Back and the Facing, press towards the back and serge.

6. Sew side seams, press towards the back and serge.

7. Serge the sleeve edges separately. Sew sleeve seam from armhole up to mark for slit, press the seam apart. Topstitch slit at 0.1 cm from fold. Sew sleeves into armholes, serge and press. Sew a gathering stitch along lower edge of sleeve and gather fullness.

8. Fold cuff in half lengthwise, right sides together and sew side seams. Turn the piece right side out, press. Sew outer side of cuff to sleeve, fold the seam allowance of the inner cuff inward and stitch in the seam attaching the outer cuff.

9. Turn hem under inside at 1 cm, then at 1.5 cm and topstitch.

10. Make buttonholes and sew on buttons onto cuffs.

Технический рисунок:

