Sleeveless Blouse - Выкройка #2648



Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 6 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 1.5 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 1 on fold
2. Front – cut 1 on fold
3. Stand collar – cut 2
4. Front neck facing – cut 1 on fold
5. Back neck facing – cut 1

Fusible interfacing:

1. Stand collar - cut 1
1. Front neck facing – cut 1 on fold
2. Back neck facing – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew the outer collar stand into the back neckline, press seam allowances towards top.

3. Make and baste pleats on the shoulder edges of the front pieces (the bulk is directed towards center). Sew shoulder seams, clip into curves, press towards back, serge.

4. Sew the inner collar stand into the neckline of the back facing, press seam allowances towards top. Sew the shoulder seams of the neckline facings, clip seam allowances and press apart. Serge the outer edge. Pin the facings onto the right side of the garment and sew the neckline and the stand collar edge. Trim away the seam allowances along the neckline, coming to zero at the mark, clip into curves. Fold away facings onto wrong side, press, slipstitch it to shoulder seams. Sew the seams of collar stands together by hand.

5. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of armhole + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to armhole edge from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along the fold. Press seam.

6. Sew side seams, press towards the back, serge.

7. Serge lower edge of garment, press onto wrong side and topstitch.

7. Sew decorative buttons on front.

Технический рисунок:



