Long Vest - Выкройка #2675



Recommendations on fabric: natural/mixed suiting fabrics.

You will also need: fusible interfacing; lining; two buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2.5 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2
5. Lower collar - cut 1
6. Upper collar – cut 1
7. Center front facing – cut 2
8. Back neck facing – cut 1

Attention: lining for front and back is cut using the pattern blocks for main fabric except for the width of the center front facing and back neckline facing.

Lining:
1. Center back – cut 2
2. Side back – cut 2
3. Center front – cut 2
4. Side front – cut 2

Fusible interfacing:
1. Center front – cut 2
2. Center front facing – cut 2
3. Back neck facing – cut 1

Инструкции:

1. Apply fusible interfacing. Apply a strap of interfacing 1 cm wide to the fold line of lapels on fronts (fusible interfacing).

2. Sew the center back seam, press the seam apart. Sew side backs to center back. Press towards center.

3. Sew side front to center front. Press towards center.

4. Sew shoulder and side seams. Press the seam apart.

5. Pin upper collar to lower collar and sew the corners and the outer edge. Start and stop sewing exactly at the marked line of the seam between collar and garment. Trim away corners, snip into seam allowance near the mark. Turn the collar right side out, straighten and press.

6. Sew and press apart the shoulder edges of the back neckline facing and of the center front facing.

7. Place center front facing onto front right sides together, pin together and sew along the center front edge. Sew upwards up to the notch marking the end of collar seam.

8. Sew the lower collar into the vest's neckline, sew the upper collar into the neckline of the back facing and of the center front facing. Press seam allowances of the collar seam apart and slipstitch them together close to the seam.

9. Fold inside the lower edge of the vest and press.

10. Sew seams on lining, leaving an opening in left side seam. Sew lining to the central front facings and to facing. Sew armhole in two steps: First sew the front armhole, then sew the back armhole. Clip seam allowances, press seam. Sew lining to lower edge of vest.

11. Turn the vest right side out through the technical opening. Sew the opening closed.

12. Make buttonholes on right front. Sew on buttons onto left front.

Технический рисунок:

