# Corduroy Jacket - Выкройка #2689

Recommendations on fabric: soft suiting fabrics, natural/mixed corduroy fabrics.



You will also need: fusible interfacing; 9 buttons.

Seam allowances: all seams – 1 cm.

**О припусках на швы::**
*- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.*
*- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.*

**О требуемой длине ткани:**
*Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.*

## РАСКРОЙ:

**Обратите внимание при раскрое:**
*Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.*
*При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.*

Pattern pieces have markings and texts from the right side. Take this into account when cutting the fabric- some of the pattern pieces need to be laid onto fabric with their wrong side on top!

Main fabric:
1. Center back - cut 1 on fold
2. Side back - cut 2
3. Back yoke – cut 1
4. Front yoke - cut 2

5. Center front – cut 2
6. Center 2 front – cut 2
7. Side front – cut 2
8. Front sleeve – cut 2
9. Back sleeve – cut 2
10. Collar – cut 2
11. Cuff – cut 2
12. Pocket welt – cut 2
13. Flap – cut 4
14. Placket – cut 1 on fold
15. Large pocket bag – cut 2
16. Small pocket bag – cut 2

Fusible interfacing:
1. Collar – cut 1
2. Cuff – cut 2
3. Flap – cut 2
4. Pocket welt – cut 2
5. Placket – cut 1 on fold

## Инструкции:

1. Apply fusible interfacing. Apply fusible interfacing to the one-piece placket on the front.

2. Sew side backs to center back. Serge seams and press towards center. Sew a decorative stitch at 0.5 cm from seam. Sew back yoke to back. Serge and press towards top.

3. Pin the pocket flaps together pairwise, right sides together and sew the side and the lower edges. Trim seam allowances, turn right side out and press. Sew a decorative stitch along the lower edge and the side edges.

4. Sew side fronts to front. Serge the seam allowances and press the seam allowances away from the central piece. Sew a decorative stitchline at 0.5 cm from the seams. Sew a decorative stitch, imitating a pocket. Sew front yoke to front, inserting flap. Serge seams and press towards top. Sew a decorative stitch at 0.5 cm from seam.

5. Mark the position of pocket. Press welt in half lengthwise wrong sides together. Topstitch small pocket bag onto inner side of welt. Sew welt to front along lower marked line of pocket. Sew large pocket bag to front along upper marked line of pocket. Stop stitching near short marking lines of the pocket. Slash through pocket opening. Snip diagonally toward end of stitching at 1-1.5 cm from end of pocket opening. Turn welt and large pocket bag onto wrong side through the resulting opening. Sew a double back stitch lines near corners to fix ends of pockets. Sew together edges of pocket bags.

6. Sew side and shoulder seams, press towards the back and serge.

7. Fold the one-piece placket on the front onto the wrong side. Sew the upper corner up to the center line. Cut the seam allowance in the corner. Snip into the seam allowance near the center line. Turn right side out and press center front edge. Turn under the longer seam allowance of the placket and topstitch.

8. Pin upper collar to lower collar, right sides together. Sew ends of collar and collar fall. Trim seam allowances. Turn the collar right side out, straighten and press. Sew a decorative stitch along the collar ends and the collar outer edge.

9. Sew the upper collar into the neckline of the garment. Fold the seam allowance of the lower collar onto wrong side and and topstitch into the seam of the upper collar.

10. Snip into the seam allowance near the mark at the front sleeve. Serge the seam allowance of the slit. Sew front sleeve to back sleeve from the top up to the mark for the slit. Serge the seam allowances and press towards back. Sew a decorative stitch along the back sleeve at 0.5 cm from the seam. Sew a fixing stitch along the slit at the front sleeve.

11. Sew sleeve seam, press towards the back and serge.

12. Sew sleeves into armholes, serge and press. Sew a gathering stitch along the lower edge of the sleeve and gather fullness at the back part of the sleeve.

13. Fold cuffs in half lengthwise right sides together and sew side edges and corner. Start and stop stitching exactly at the marked line of the cuff seam. Turn the piece right side out, press. Sew outer side of cuff to sleeve, fold the seam allowance of the inner cuff inward and stitch in the seam attaching the outer cuff.

14. Fold the lower placket in half lengthwise right sides together and sew side edges. Start and stop stitching exactly at the marked seam line plackets. Turn the piece right side out, press. Sew the outer side of the placket to the hem of garment, turn seam allowance of inner side of placket under and stitch-in-the-ditch along seam of outer placket. Sew decorative stitches along all the edges of the placket.

15. Make button holes on the right front, on the cuffs, and on the pocket flaps. Sew on buttons onto left front, pockets and cuffs.

## Технический рисунок:

