

Blouse With Flounces - Выкройка #2706

Recommendations on fabric: well draping natural/mixed fabrics suitable for blouses with elastane.

You will also need: fusible interfacing; 1 button.

Seam allowances: Seam allowance for hem of garment - 2 cm; other seams - 1 cm.

О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.

- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:

Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.



РАСКРОЙ:

Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Center back - cut 2
2. Side back - cut 2
3. Center front - cut 1
4. Side front - cut 2
5. Flounce 1 - cut 2
6. Flounce 2 — cut 2
7. Back neck facing - cut 2

8. Front neck facing - cut 1

Fusible interfacing:

1. Back neck facing - cut 2
2. Front neck facing - cut 1

Инструкции:

1. Apply fusible interfacing.
2. Sew the shoulder edges of the center back and the center front. Press the seam apart and serge.
3. Sew shoulder seam of the side pieces. Serge and press towards back.
4. Serge the outer edge of the flounces, fold inside and topstitch. You may also finish the edge with baby hem, in this case trim away the seam allowance.
5. Sew the princess seams on front and back continuously, inserting the flounce into the seam 1. Serge seam and press towards center.
6. Serge the center back edges separately. Sew center edge from the marking for slit down to the lower edge. Press the seam allowances apart.
7. Sew side seams, press towards the back and serge.
8. Cut (or take ready) bias tape, its width should equal 2.5 cm and its length should equal 10 cm for loop buttonhole. Fold tape in half lengthwise right sides together and stitch at 0.3 cm from fold. Cut away seam allowances close to seam, turn tape right side out and straighten the rolled piece. Adjust length of the loop.
9. Sew shoulder seam on front neckline facing and back neckline facing, press the seam apart. Serge the outer edge. Pin the facing onto the right side of garment and sew neckline. Clip seam allowances, fold facings onto wrong side and press neckline edge. Sew the facing to center back seam by hand, inserting the loop buttonhole.
10. Sew flounce 2 to the sleeve cap. Serge and press towards flounce.
11. Cut (or take ready) bias tape, its width should equal 4 cm and length should equal the length of lower armhole + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to armhole edge from the right side and sew. Fold bias tape onto wrong side, clip into seam allowances and topstitch onto main piece along the fold. Press seam.
12. Serge the lower edge of garment, turn inside and topstitch.

13. Sew on button on the back piece.

Технический рисунок:

