Blouse With Flounce - Выкройка #2737



Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 5 buttons.

Seam allowances: Seam allowance for hem of garment – 2 cm; other seams – 1 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back - cut 1 on fold
2. Front - cut 2
3. Cap Of Sleeve – cut 4
4. Right collar — cut 2
5. Left collar – cut 2
6. Center front facing – cut 2
7. Back neck facing – cut 1

Fusible interfacing:
1. Right collar — cut 1
2. Left collar – cut 1
3. Center front facing – cut 2
4. Back neck facing – cut 1

Инструкции:

1. Apply fusible interfacing.

2. Sew front darts, press bulk towards top.

3. Sew shoulder seams, press towards the back and serge.

4. Sew the central edges of the left collar and of the right collar. Press the seam apart. Pin upper collar to lower collar, right sides together, sew the collar edge and the end of the left side. Trim seam allowances, turn the collar right side out, straighten and press. Make a pleat at the neckline edge on the right side according to the technical drawing and baste the pleat to prevent shifting. Sew the collar into the neckline. Sew the right long side to the front center edge.

5. Sew shoulder seams of back neckline facing and central front facing, press the seam apart. Serge the outer edge. Pin the facing and the center front facing onto the right side of the garment and sew neckline and center front facings. Clip seam allowances, trim away corners, fold away facings and center front facing onto wrong side and press. Sew the facing to the shoulder seams by hand.

6. Pin the wing sleeves together, right sides together and sew the outer edges. Trim seam allowances, turn right side out and press. Sew the wing sleeves into the armholes. Serge and press.

7. Sew side seams, press towards the back and serge.

8. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of lower armhole + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape to armhole edge from the right side and sew. Clip into seam allowances. Fold bias tape onto wrong side and topstitch onto main piece along the fold. Press seam.

9. Turn hem under inside at 1 cm, then again at 1 cm and topstitch.

10. Make buttonholes on right front, folding the collar away, sew on buttons on the left one.

Технический рисунок:



