

Blouse With Pleats At The Neckline - Выкройка #2746

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing; 8 buttons.

Seam allowances: seam allowance for hem of garment - 2.0 cm; other seams 1 cm.

О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.

- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:

Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.



РАСКРОЙ:

Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Back - cut 1 on fold
2. Yoke - cut 1 on fold
3. Front - cut 2
4. Stand collar - cut 2
5. Center front facing - cut 2
6. Sleeve - cut 2
7. Cuff - cut 2

Fusible interfacing:

1. Stand collar - cut 1
2. Center front facing - cut 2
3. Cuff - cut 2

Инструкции:

1. Apply fusible interfacing.
2. Make and baste pleats on fronts. Fold bulk towards side. Pin the center front facing to the front right sides together and sew center front edge. Clip seam allowances, turn center front facing onto wrong side, straighten, press.
3. Sew outer stand collar into neckline yokes, clip seam allowances, press towards stand collar. Fold under the seam allowance of the inner stand collar and press. Pin stand collars together, right sides together and sew upper edge. Start and stop stitching exactly at the marked line of the side edge.
4. Sew shoulder seams, inserting the front in between the back and the inner stand collar. Press seams towards back and serge. Turn stand collar right side out, topstitch the inner stand collar into the seam between outer stand collar and the main piece.
5. Sew yoke to back, press seam allowances towards top and serge.
6. Sew side seams, press seam allowances towards back and serge.
7. Serge the sleeve edges separately. Sew sleeve seam from armhole up to mark for slit, press the seam apart. Topstitch slit at 0.1 cm from fold. Sew sleeves into armholes, serge and press.
8. Fold cuffs in half lengthwise right sides together and sew side edges. Start and stop stitching exactly at the marked line of the cuff seam. Turn the piece right side out, press. Sew outer side of cuff to sleeve, fold inside the seam allowance of the inner cuff and topstitch into the seam of outer cuff.
9. Serge the lower edge of garment, press onto wrong side and topstitch.
10. Make buttonholes on right front, sew on buttons on the left one. Make buttonholes and sew on buttons onto cuffs.

Технический рисунок:

