Blouse With Decorative Front - Выкройка #2766

Recommendations on fabric: natural/mixed fabrics suitable for blouses.

You will also need: fusible interfacing, dress zipper, 2 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2.5 cm.



О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back yoke – cut 2
2. Lower back – cut 1 on fold
3. Left front – cut 1
4. Right front – cut 1
5. Stand collar – cut 2
6. Sleeve - cut 2
7. Cuff – cut 2

Fusible interfacing:
1. Stand collar – cut 2
2. Cuff – cut 2

Инструкции:

1. Apply fusible interfacing to the mentioned pieces and to the one-piece center front facings.

2. Pin together parts of stand collar, right sides together and sew upper edge. Clip into curves, turn stand collar right side out, straighten and press. Serge lower edge of inner stand collar.

3. Serge the outer edges of the one-piece center front facings on the fronts. Press center front facings onto wrong side. Pin the left front onto the right front and baste together along the neckline's edge and along the shoulder edge.

4. Sew shoulder seams, press towards the back, serge.

5. Serge the central edges of the back yokes. Sew outer stand collar into neckline, press seam allowances towards stand collar. Sew the zipper, starting at the upper edge of stand collar, folding away the inner stand collar. Fold inside the shorter seam allowances of the inner stand collar and sew them to the zipper tape. Topstitch the inner collar in the seam of the outer collar.

6. Sew upper back to lower back, press seam allowances down, serge.

7. Sew sleeves to garment, press seam allowances towards sleeve and serge.

6. Serge the sleeve edges separately and side edges. Sew the side seam, and continue sewing the seam of the sleeve up to the mark for the slit, press the seam apart. Topstitch slit at 0.1 cm from fold. Make and baste pleats along the lower edge of the sleeve.

7. Pin cuffs together, right sides together and sew side edges. Start and stop stitching exactly at the marked line of the cuff seam. Turn the piece right side out, press. Sew outer side of cuff to sleeve, fold the seam allowance of the inner cuff inward and stitch in the seam attaching the outer cuff.

8. Serge lower edge of garment, press onto wrong side and topstitch.

9. Make buttonholes on cuffs, sew on buttons.

Технический рисунок:

