Dress-Jacket - Выкройка #2774

Recommendations on fabric: natural/mixed suiting fabrics.



You will also need: fusible interfacing; lining; shoulder pads; 6 main buttons; 8 buttons for the vents on sleeves.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment and hem of sleeve – 3.0 cm.

О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Center back – cut 2
2. Side back – cut 2
3. Lower back left – cut 1
4. Lower back right – cut 1
5. Side front right – cut 1
6. Center front right – cut 1
7. Center front left – cut 1

8. Side front left – cut 1
9. Lower front left – cut 1
10. Lower collar - cut 1
11. Upper collar – cut 1
12. Center front facing – cut 2
13. Back neck facing – cut 1
14. Upper sleeve – cut 2
15. Lower sleeve – cut 2

Lining:
1. Center back – cut 2
2. Side back – cut 2
3. Center front left – cut 2
4. Side front left – cut 2
5. Upper sleeve – cut 2
6. Lower sleeve – cut 2

Attention! Front and back from lining are cut using the pattern blocks for self fabric, with the exception for the areas of center front facing and back neckline facing.

Fusible interfacing:
1. Center front left – cut 2
2. Center front facing – cut 2
3. Back neck facing – cut 1
4. Upper collar - cut 1

Инструкции:

1. Apply fusible interfacing. Apply fusing on front along the lapel fold , its width should equal 1 cm (fusible interfacing).

2. Sew the center back seam, press the seam apart. Sew the princess seams on the back (sew center back to side back), press the seam apart.

3. Sew left lower back to right lower back, press seam, serge. Make and baste pleats on lower back. Sew upper back to lower back, press seam allowances towards top, serge.

4. Sew the right princess seam on the front (sew side front to center front), press the seam apart.

5. Sew the princess seam on the left front (sew side front to center front), press the seam apart. Make and baste pleats on the left lower front. Sew upper front to lower front, press seam allowances towards top, serge.

6. Sew and press apart shoulder and side edges.

7. Pin upper collar to lower collar and sew the corners and the outer edge. Start and stop sewing exactly at the marked line of the seam between collar and garment. Trim away corners, snip into seam allowance near the mark. Turn the collar right side out, straighten and press.

8. Sew side seams of back neckline facing and central front facings, press seam apart. Place central front facings onto front, right sides together, pin together and sew along the center front edge. Sew upwards up to the notch marking the end of collar seam. Trim away corners. Topstitch seam allowance along center front edge onto center front facing along the closure, and onto front along the part, which is folded away. Place stitch line at 0,2 cm from seam. Turn center front facings right side out, straighten seams.

9. Sew lower collar into the neckline of the garment, sew upper collar into the neckline edge of the back neckline facing and into the neckline edge of the center front facing. Press seam allowances of the collar seam apart and slipstitch them together close to the seam.

10. Sew the elbow seam on the sleeve, press apart the seam and the corners of the slit on the lower and the upper sleeves. Press the elbow seam on the sleeve, snip into seam allowances, and press the vent. Sew a slanted fixing stitch along the vent of the sleeve. Press the hem of sleeve. Sew and press apart front sleeve seam. Sew sleeves into armholes matching notches, adjusting ease on sleeve cap. Sew shoulder pads.

11. Sew seams on lining and sew in sleeves. Serge lower edge. Sew lining to inner edges of the central front facings and to back neckline facing (the lining reaches the seam of the lower part). Sew lining to hem of sleeve. Turn jacket right side out. Sew the lower edge of lining to the seam allowance of the seam of the lower part by hand.

12. Seam allowance along hem serge, press onto wrong side and topstitch.

13. Make buttonholes on right front, sew on buttons onto left front. Sew on buttons on the sleeves' vents.

Технический рисунок:

