

Vest With Shawl Collar - Выкройка #2802

Recommendations on fabric: thick natural/mixed fabric suitable for dresses.

You will also need: fusible interfacing; 3 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 2.0 cm.

О припусках на швы::

- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.

- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:

Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.



РАСКРОЙ:

Обратите внимание при раскрое:

Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроются со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.

При стачивании деталей, обращайтесь внимание на надсечки, они должны совпадать.

Main fabric:

1. Upper center back – cut 2
2. Upper side back – cut 2
3. Lower back – cut 1 on fold
4. Upper center front – cut 2
5. Upper side front – cut 2
6. Lower front – cut 2
7. Center front facing – cut 2

8. Back neck facing – cut 1

Fusible interfacing:

1. Center front facing – cut 2
2. Back neck facing – cut 1

Инструкции:

1. Apply fusible interfacing.
2. Sew center seam on upper back, press towards left, serge. Sew the princess seams on upper back (sew upper side back to upper center back), press seam allowances towards center, serge. Sew upper back to lower back, press seam allowances towards top, serge.
3. Sew side upper front to center upper front, press seam allowances towards center, serge. Sew upper front to lower front, press seam allowances towards top, serge.
4. Pin fronts right sides together and sew the collar seam, press the seam apart. Sew the shoulder seams and press the seam allowances apart, serge. Clip into seam allowance of shoulder seam on front and sew in the collar into the back neckline, press seam allowances towards the collar.
5. Sew the shoulder seams of back neckline facings and center front facings, snip into corner and press apart. Sew collar edge, press the seam apart. Sew the collar into the facing's neckline, press the seam apart. Serge the outer edge of center front facings and of neckline facing.
6. Pin center front facings and the facing to the garment, right sides together, and sew the center front edge, the collar, and the lower corner. Trim away corners, clip into curves. Fold the center front facings onto right side, straighten seams, press. Slip stitch together seam allowances along collar seams.
7. Cut or use ready-made bias tape, its width should equal 4 cm and length should equal the length of armhole + 4 cm. Fold bias tape in half lengthwise right side out and press. Pin bias tape onto armhole edge from the right side and sew. Fold bias tape onto wrong side and topstitch onto main piece along the fold. Press seam.
8. Sew side seams, press towards the back and serge.
9. Serge lower edge of garment, press onto wrong side and topstitch.
10. Make buttonholes on right front, sew on buttons on the left one.

Технический рисунок:

