Wrap Blouse - Выкройка #2816

Recommendations on fabric: natural/mixed fabrics suitable for blouses with elastane.

You will also need: fusible interfacing; 4 buttons.

Seam allowances: all seams 1 cm. Seam allowance for hem of garment – 1.5 cm.



О припусках на швы::
- Если на выкройке двойной контур, припуски на швы уже включены. Они составляют 1 см, если не указано иначе.
- Если у выкройки одинарный контур, припуски на швы не включены, и должны быть добавлены при раскрое.

О требуемой длине ткани:
Внимание! В инструкциях не указано необходимое количество ткани, так как оно зависит от ширины и рисунка ткани, а также Ваших размерных признаков. Прежде всего, распечатайте лекала и разложите их на ширине, соответствующей ширине ткани, которую Вы хотите использовать (обычно от 90 до 150 см), чтобы определить, сколько ткани Вам потребуется. Не забывайте учитывать парные детали и детали со сгибом.

РАСКРОЙ:

Обратите внимание при раскрое:
Обратите внимание на обозначение долевой нити при раскладке деталей. Некоторые детали кроятся со сгибом. Это указано на лекале. Перенесите все отметки и другие особенности дизайна (вытачки и т.п.) с лекала на ткань.
При стачивании деталей, обращайте внимание на надсечки, они должны совпадать.

Main fabric:
1. Back – cut 1 on fold
2. Front – cut 2
3. Front neck facing – cut 2
4. Back neck facing – cut 1
5. Collar – cut 1
6. Sleeve – cut 2
7. Cuff – cut 2

Fusible interfacing:
1. Front neck facing – cut 2
2. Back neck facing – cut 1
3. Collar – cut 1
4. Cuff – cut 2

Инструкции:

1. Apply fusible interfacing.

2. Sew front darts (if the size implies these), press bulk towards top.

3. Sew shoulder seams, press towards the back and serge.

4. Fold collar in half lengthwise, right sides together and sew corners. Trim seam allowances, turn the piece right side out, straighten and press. Sew collar into neckline.

5. Sew shoulder seams of facings, press the seam apart. Serge the outer edge. Pin facing to garment right sides together and sew the neckline. Clip into curves, fold facing onto wrong side and press. Baste facing to garment along shoulder seams.

6. Put right front onto left front and baste together along side edge. Sew side seams, press towards the back and serge.

7. Serge the sleeve edges separately. Sew the sleeve seam from the top up to the mark for slit, press the seam allowances apart. Sew a fastening stitch along the slit at 0.3 cm from the edge.

8. Sew sleeves into armholes, seam allowance press and serge. Sew a gathering stitch along the lower edge of sleeve and gather fullness.

9. Fold cuff in half lengthwise, right sides together and sew short sides. Turn cuff right side out, straighten and press. Sew outer side of cuff to sleeve, fold the seam allowance of the inner cuff inward and stitch in the seam attaching the outer cuff.

10. Serge lower edge of garment, press onto wrong side and topstitch.

11. Make buttonholes on cuffs and sew on buttons.

Технический рисунок:

